

User Manual

Keyboard Operating steps:

1、The wireless keyboard uses two AA alkaline batteries.

- a) Open the battery cover at the bottom of the keyboard.
- b) Insert the two AA batteries.
- c) Replace the cover after the batteries are installed.

2、Press the connect button at the bottom of the keyboard.

3、The wireless keyboard comes with eleven internet keys and four media player keys. All of these hot keys are compatible with Windows ME, 2000, XP.

4、The functions of eleven internet keys

(1) Backward	(2) Internet	(3) Forward
(4)Search	(5) Refresh	(6)Favorite
(7)E-mail		

5、The functions of 8 media player keys

(1) Play/Pause	(2) Media Stop	(3) Volume UP
(4) Mute	(5) Volume DOWN	(6)Previous
(7)Next	(8) Media	

6、The functions 2 of operation system keys

(1)My computer	(2) Calculator
----------------	----------------

7、Press the key of Fn+F11 at same time can lock the keyboard.

Keyboard Specification

Transmission Distance	1—1.2 m
Battery Type	2 * AA Battery
Battery Life	6 Month
Power Consumption (Working)	3mA (Typical)
Power Consumption (Suspend)	20uA
Storage Temperature	-15 ~ +85 ° C
Working Temperature	-10 ~ +60 ° C
Power Supply	DC 3 V From Battery AA size X 2 pcs.
Operating Frequency	27.045MHz
Transmit Power	0.1Mw Max.
Modulation Technique	Frequency Shift Keying (FSK)
Number of Channels	1 Channel
Operating Mode	Point-to-Point
Antenna Designation	Internal loop, which is built in EUT

FCC Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCC grant.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.