

**Introduction:**

This wireless optical mouse set consists:  
Mouse

2 AAA rechargeable batteries

**System Requirements:**

Hardware:  
IBM PC or compatible  
USB Port (PS/2 Optional Model)  
Operation system:  
Windows 98SE/ME/2000/XP

**Caution: The scrolling wheel and the third button only work with the above operation system, otherwise the mouse equal to the standard two button mouse.**

**Insert the batteries (see figure):**

1. Put the On/Off switch on the bottom of the mouse to the "OFF" position.
2. Press the battery cover button on the top of the mouse then remove the battery cover from the top of the mouse.
3. Making sure the batteries positive (+) and negative (-) ends of each battery match the polarity indicators inside the battery housing.

**Note: The battery cover is top cover of the mouse.**

4. Close the battery cover.
5. Put the On/Off switch on the bottom of mouse to the "ON" position. The optical sensor located on the bottom of the mouse will glow red.

**Set the ID codes:**

1. Press the link button on the receiver.
2. Press the link button on the bottom of mouse. When you see the red light flashing that means the mouse and receiver are communicating successfully.

**Mouse power management:**

1. The mouse depend the "On/Off" switch control the power.
2. When power is "ON", the mouse will goes into "Sleep Mode" after 8 minutes if not use. You need press the button or scroll the wheel to activate the mouse.
3. To save the power, turn off the power while you are not using it or traveling.
4. When the low battery indicator is flashing, it means the power is not enough. You would better plug the charging cable on both receiver & mouse for charging. Make sure the mouse contains rechargeable batteries.
5. The charging indicator light is located at the end of transmitter (mouse). When plug the charging cable, the red LED will be on. When the battery is fully charged, the LED will turn to green.

**Note: Please charge at least 10 hours for the first usage. Make sure PC or notebook is not in stand by or sleep mode.**

**WARNING STATEMENT:**


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.