


F+SERIES


Digital Scale RC Helicopter Series



Users' Manual for Remote Controlled Helicopter

1. Intelligent control system.
2. Full-scale remote control.
3. 360° accurate orientation.
4. Properties of smooth suspension.
5. Newly R & D electricity-saving function.
6. Care about battery mode, extend its service life.
7. Unique accelerator key function.
8. The most advanced battery replacement mode.
9. The keys on the original unprecedented joystick double Heavy side fly operating mode.

Name of parts contained



Assembled remote controller

1. Installation of antenna: rotate antenna clockwise and install it into the antenna terminal screw post of remote controller. (as figure 1)
2. Installation method of battery: Open the battery cover on the back of remote controller. Four #5 alkaline batteries should be installed correctly in accordance with the instructions on battery box (batteries shall be purchased separately). (as figure 2)



Fig.1

Notes:

1. When inserting batteries, user must check the positive and negative poles of batteries and the positive and negative terminals of battery box. Do not mingle them.
2. Do not use old and new batteries blended.
3. Do not use different types of batteries blended.




Fig.2

Model No. F101 F102 F103 F105 F106 F107 F108 F109 F180 F181 F182 F183 F185 F186 F187 F188 F189 F161 F162 F163

statement:

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.