

USER MANUAL

49MHZ Radio Control Car model AD 747-099 Scale 1:6



IMPORTANT

Not suitable for children under 3 years of age due to small parts and sharp edges. Children from 3 to 6 years of age only under supervision of an adult.



AGE
3-6

FCC ID: S3A747RCCAR49M
MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Don't use the car on the public road.

While driving with 2 cars be sure they don't have the same frequency. The frequency is indicated on the car and on the remote control

Frequency is 27.145 MHz or 40.680 MHz. Look for the right frequency on the bottom of the car. These frequencies are allowed in most of the European countries. Please check whether this frequency is allowed in other countries before using the car.

While driving with 2 cars be sure they don't use the same frequency.

5. READ THIS FIRST.

Please start by reading the cautions first.

Do not throw the user manual away. Store it in a safe place for future reference.

6. CAUTIONS.

- a. Before the product can be used you have to charge the battery. Use the enclosed power adapter
- b. Only use the official delivered battery charger and remote controller.
- c. Check before using the adapter the strength of the electricity. Standard is 220 Volt.
- d. The time to charge the battery is max. 6 hours. **IMPORTANT:** do not charge any longer.
- e. Make sure the car and remote control are put OFF while installing the batteries.
- f. If the car remains unused for a certain period of time switch the car *AND* the remote control both OFF.
- g. Take the plug of the charger out of the (plug) socket when not using it.
- h. Do not use the car on a sandy or wed location or a location affected by water or steam.
- i. Do not use the adapter on a dusty or wed location or a location affected by water or steam.
- j. Keep away from children under the age of 6 years when you're not able to supervise.
- k. Do not try to modify the product. This may cause an electric shock or other personal harm.
- l. Do not take unnecessary risks
- m. Internal inspection, maintenance and repairs should only be carried out by authorized personal.
- n. When in doubt regarding the use of the Radio Controlled Car always contact authorized persons, retailer or supplier.

GETTING STARTED

Make sure the car and remote control are put OFF.

On the bottom of the car you find a cover. Open it with a screwdriver. Insert the batteries, noting correct polarity (+ and -). Close the cover firmly.

Next you may insert the 8 AA batteries in the remote control. On the bottom of the remote control you find a cover. Insert the batteries, noting correct polarity (+ and -).

Screw the antenna on the remote control.

The car is now ready to use.

Turn the car ON by sliding the power switch (bottom of the car)

Turn the remote control ON by sliding the power switch (to the front).

The car can be moved by pulling or pushing the trigger. Use the steering wheel to drive.

Recharge the batteries, once they are empty.

In case the car is not driving straight, you can adjust the adjusting screw between the front wheels.

“Modifications not authorized by the manufacturer may void users authority to operate this device”

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Used batteries must not be discarded in the rubbish bin as it is dangerous for the environment. These should be discarded in official bins for used batteries

NOTE

The frequency is not allowed in every country.

Please check whether this frequency is allowed in other countries before using the car.