

Vivitar® Infinite BH-C26 Bluetooth® Headphones

User Guide

Thank you for purchasing the Vivitar® Infinite BH-C26 Bluetooth® Headphones.

Introduction

With these headphones, you will enjoy listening to high quality music wirelessly using Bluetooth® technology. Easily connect to any mobile phone for both conversation and music listening. It also pairs with other Bluetooth-enabled devices (Bluetooth V2.1+EDR specification and HSP, HFP, A2DP and AVRCP profiles).

Specifications

- Bluetooth Specification: V2.1+EDR
- Operation Frequency: 2.402-2.48GHz
- Supported Profile: HSP, HFP, A2DP, AVRCP
- Operation Range: Up to 33 feet (10 meters)
- Talk Time: 4 hours
- Play Time: 3 hours
- Standby Time: 7 hours
- Battery Type: 120mAh, 3.7V, Polymer Lithium Ion Battery
- Charge Time: 2 Hours

In the Box

- BH-C26 Bluetooth® headphones
- USB Charging Cable
- User Manual

Safety Precautions

- Please read this User Manual carefully and follow all instructions.
- To avoid damage or malfunction of the headphones do not drop them from high locations and/or on to hard surfaces, do not place heavy objects on them.
- Keep headphones away from humidity, water and other liquids. If they get wet, do not operate as this may cause an electrical shock, explosion and damage to the device or to the user.
- Do not place or keep this product near heat sources, such as direct sunlight, radiators, stoves or any other apparatus that produces heat. This may cause an explosion, degrade the performance and/or reduce battery life.
- Do not modify, repair or disassemble device (especially the battery). Doing so will void the warranty. The battery in this device may present a risk of fire or chemical burns if misused or tampered with.
- Use only supplied and manufacturer-approved chargers and unplug this device when not in use for long periods of time or during lightning storms.

FCC and IC Statement

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

EC Declaration of Conformity


Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. This product is CE certified according to the provision of the R&TTE Directive (99/5/EC). This declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Please note that this product uses radio frequency bands not harmonized within EU. Within the EU this product is intended for use in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg, the Netherlands, Portugal, Spain, Sweden, and United Kingdom and within EFTA in Iceland, Norway and Switzerland.

Location of Controls (Drawing FPO)

- ① Next Track / Volume +
- ② Power / Play / Pause / Answer
- ③ Previous Track / Volume -
- ④ Charging Port
- ⑤ Auxiliary Port
- ⑥ Microphone
- ⑦ Indicator LED



First Time Use

Charging the Battery

The BH-C26 Headphones have a built-in, rechargeable lithium-polymer battery. To avoid damage, do not attempt to remove the battery. The full performance of the battery is achieved after two or three charging-discharging cycles. Charge the battery fully before first use.

1. Connect the USB cable to the headphones.
2. Connect to the correct outlet (wall, computer, car charger).
3. When the charger is connected to the headphones, the red indicator light will turn on.

Note: Charging the battery fully may take up to 2 hours.

4. When the battery is fully charged, the red indicator light will turn off. Disconnect the charger from the headset and the outlet. The headset is ready for use.

Note: Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

Important!

Ensure that the battery is fully charged if the headphones are not used for a long period of time. To avoid a complete discharge of the battery, charge the headphones at least every six (6) months.

Battery Notes

- A fully charged battery provides up to four (4) hours of talk-time, three (3) hours music playback, and up to seven (7) hours of standby time. Talk and standby times vary depending on mobile phones or other compatible Bluetooth® devices, settings, styles, etc.
- When the battery power is low, the headset will beep every 30 seconds and the red indicator light will flash every seven (7) seconds.
- When using with your iPhone, an additional battery meter feature will display the remaining battery on your phone's touch screen.

Pairing with your Phone

1. Place the headphones in close range of a Bluetooth®-enabled mobile phone.
2. Press and hold POWER button for three (3) seconds. Until indicator lights flash blue and red.
3. Set your mobile phone to pairing mode (as explained in operating instructions for your phone) and search for Bluetooth® devices.
4. Select "Vivitar HP" from the list shown on your phone.
5. If requested, enter the PIN code "0000" and confirm the entry. Once the pairing is successful, the BH-C26 connects to your phone automatically before switching to standby mode. The indicator will blink blue twice every three (3) seconds.

Note: If pairing is not completed within two (2) minutes, the headset will enter standby mode. If this happens, turn the headset off and repeat the pairing steps above.

General Operation


Turning ON/OFF

1. Press and hold the POWER button for three (3) seconds to turn the headphones ON. If pairing was successful (instructions above), the headphones will remain paired to your mobile device.
2. Press and hold the POWER button for seven (7) seconds to turn the headphones OFF.

Note: The headphones will turn OFF automatically when not connected to a mobile device for approximately ten (10) minutes.


Music Playback (Picture FPO)

- **Play/Pause** button: Press to play or pause music playback.
- **Next Track / Volume +** button: Press to increase sound level. Press and hold to skip to the next track.
- **Previous Track / Volume -** button: Press to decrease the sound level. Press and hold to return to the previous track.



Using the Phone Function (Picture FPO)

- **Last Number Re-dial:** In standby mode, press the ANSWER button twice to re-dial the last number called.
- **Answering a Call:** Short press the ANSWER button to answer an incoming call.
- **Reject an Incoming Call:** Press and hold the ANSWER button for two (2) seconds to reject an incoming call.
- **Transferring a Call:** Press and hold Next Track / Volume + button for two (2) seconds to transfer a call from the phone to headphones.
- **Ending a Call:** Short Press the ANSWER button to end a call.
- **Call Waiting:** If there is an incoming call while a call is already in progress there are two options: Answer the incoming call ending the current call; or answer the incoming call placing the current call on hold.
 - o To answer the incoming call and end the current call, short press the ANSWER button.
 - o To answer the incoming call and place the current call on hold, press and hold the ANSWER button. To return to the call on hold, press and hold the ANSWER button again.



Warranty Information

This warranty is non-transferable and is limited only to the original purchaser. The conditions of this warranty and supplier's responsibilities under this warranty are as follows:

- You must be able to prove the date of original purchase of the unit with a dated receipt.
- The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by an unauthorized third party.

- Supplier's responsibility shall be limited to the repair or replacement of the product at its sole discretion.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- Supplier is not responsible, for failure resulting from accident, abuse, misuse, or any unauthorized repair, or modification.
- Modification and repair of the unit should be done by an authorized and qualified service center or returned to the manufacturer.
- This warranty gives you specific legal rights, and you may also have other rights, which vary under local laws.

What is Covered

This warranty covers for the original consumer purchaser only and is not transferable. Products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship will be repaired at no charge for parts or labor for a period of one year from the time of purchase.

What is NOT Covered

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accidents.

Service and Returns

When returning a defective product (postage pre-paid) for service, the package should include:

1. Copy of original bill of sale.
2. A detailed written description of the problem.
3. Your return address and telephone number (Daytime).

Where to send defective products

United States	United Kingdom / Europe	Australia
Sakar International	Sakar International	Return faulty device to the
Attention: Service Department	Attention: Service Department	Refund Counter at the store
195 Carter Drive	2D, Siskin Parkway East	where the product was
Edison, NJ 08817	4020 Middlemarch Business Park	purchased.
	Coventry, CV3 4PE	

Technical Support

For technical support issues, visit our website at www.vivitar.com. Manuals, software and FAQ's are available on line. If you can't find what you are looking for, e-mail us at support@vivitar.com where one of our technical support team members will help you. US phone: 1-800-592-9541; UK phone: 0800 917 4831; Australia phone: 1800-006-614. Telephone numbers from other countries can be found at: www.vivitar.com.