



Bluetooth Stereo Earphones

Operation Manual

Thank you for purchasing the SH805C Bluetooth Stereo Earphones. Please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS

- . Bluetooth Stereo Earphones
- . USB Charging Cable
- . 1 Extra Sets of Ear Cushions
- . Operation Manual

KEY FEATURES

- . Compatible with Bluetooth-enabled devices
- . Built-in rechargeable battery
- . Volume control

SAFETY INSTRUCTIONS

Keep the unit away from heat sources. Direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be

performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.


This product is not a toy. Keep out of reach of children.

Do not use the headset at excessive levels as this may damage hearing.

Do not expose batteries, battery pack, or batteries to installed to excessive heat, such as direct sunlight or open flame.

FEATURES/PARTS

1. Power On/Off
Multifunction Button
Answer/End Cal
2. Indicator LED
3. Volume Up/Next Track
4. Volume Down/Previous Track
5. Charging Port
6. Microphone



CHARGING THE EARPHONES

The earphones come with a built-in rechargeable battery. Before using it for the first time, we recommend you charge the battery fully. Only use the supplied USB cable to charge the headphones.

Connect the USB cable to a computer USB port and the USB plug to the charging jack of the headset. The red LED light will illuminate while the earphones are charging. A full charge of the battery takes around 2 hours. When the battery is fully charged, the LED light will turn blue.

Disconnect the headset at this point. The headset will then be ready for use.

When the battery is low, the LED will flash red and emit

Voice prompt every 20 seconds. When this occurs, please recharge the headset.

When using your earphones with an iPhone, the top right corner will indicate your ear bud's battery life.

VOICE PROMPT

The earphone will notify you of status by tones "Power On", "Power Off", And "Pairing code" "connected"; when applicable.

TURNING HEADSET ON/OFF

Power On: Press and hold the Power On/Off button for 3seconds until the LED flashes blue.

Power Off: Press and hold the Power On/Off button for

5seconds until the LED flashes red.

In order to save power, the headset will automatically turn off if not paired with a device after 10 minutes.

PAIRING THE EARPHONES

- 1 . Ensure the earphones are turned off. If they are not, please turn off the earphones first before pairing.
2. Press and hold the Power On/Off button for 5-7seconds until the LED flashes red and blue. This will indicate your earphones are now in pairing mode.
3. Place the earphones and the Bluetooth device to which you would like to pair it within the operating distance. We recommend keeping the two devices no further than 3 feet apart.

4. Ensure Bluetooth is enabled on your phone or music device. Refer to the manufacturer's instructions for how to enable Bluetooth on your device.
5. Once you have activated Bluetooth on your device, select the earphones 'MERCURY BTE41' from the list of available Bluetooth devices.
6. Please note, pairing mode on the earbuds will last for two minutes. If no devices are paired after two minutes, the earphones will automatically switch off.
7. If pairing is unsuccessful, turn off the earphones first and repeat following the aforementioned steps. Once you have paired the earphones with a device. The earphones will remember this device and will pair automatically when the device's Bluetooth is activated

and in range. You do not need to re-pair any previously connected devices.

Your earbud can pair up to two multi-point devices. You can reconnect a previously paired device without going through the pairing or PIN process on up to two devices. During use, the battery life of your earphones is visible on your iPhone or iPad screen.

LISTENING TO MUSIC

Once the earphones are paired to your device, you can stream music wirelessly to the earphones. Select the track you wish to listen to on your device to listen via earphones. Should you encounter any problems while streaming, please refer to your device's user manual.

MANUAL KEY FUNCTIONS

Your earphones are equipped with a few shortcut keys.

Please note the following functions.

1. Increase Volume: Press the Vol + Button once
2. Decrease Volume: Press the Vol - Button once
3. Play/Pause: Press the Multifunction Button
4. Previous Track: double press the the Vol - Button
5. Next Track: double press the Vol + Button

CARE AND MAINTENANCE

. Do not expose the headset to liquid, moisture, or humidity to avoid damage to the product's intimal circuitry.

- . Do not use abrasive cleaning solvents to clean the unit.
- . Do not expose the headset to extremely high or low temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- . Do not dispose of the earphones in fire as they may explode or combust.
- . Do not expose the earphones to contact with sharp objects as this will cause scratches and damage
 - . Do not let the earphones fall from high places. as doing so may damage the internal circuitry.
 - . Do not attempt to disassemble the earphones. In the event that the earphones do not function properly

return it to the store where it was purchased.

SPECIFICATIONS

Bluetooth:V3.0 + EDR, Class II

Bluetooth Profiles: HSP, HFP, A2DP and AVRCP

Operating Distance: Up to 33ft (10 m)

Play Time: Up to 4 Hours

Talk Time: Up to 5 Hours

Standby Time: Up to 100 Hours

Charging Input: DC 5V

Charging Time: 2 Hours

Warranty

The condition of this warranty and supplier's responsibilities under this warrant/ are as follows:

Warranty is non-transferable and is limited to the original purchaser only.

- You must be able to prove the date of original purchase of the unit with a dated receipt.
- The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by an unauthorized third party.
- Supplier's responsibility shall be limited to there pair or replacement of the product at if's sole discretion.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and

tear such as batteries, decorates and other accessories.

- Supplier is not responsible, for failure resulting from accident, abuse, misuse, or any unauthorized repair or modification.

- Modification and repair of the unit should be done by an authorized and qualified service center or returned to the manufacturer.

- This warranty gives you specific legal rights, and you may also have other rights, which vary under local laws.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.