


TRACKMAN
UNLEASH YOUR POTENTIAL



INSTRUCTION

READ THIS INSTRUCTION BEFORE USING YOUR TRACKMAN

US/CA - READ THIS INSTRUCTION BEFORE USING YOUR TRACKMAN

REGULATORY NOTICE

FCC and IC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This Class B digital apparatus complies with Canadian ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

This device complies also with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

LE PRÉSENT APPAREIL EST CONFORME AUX CNR D'INDUSTRIE CANADA APPLICABLES AUX APPAREILS RADIO EXEMPTS DE LICENCE. L'EXPLOITATION EST AUTORISÉE AUX DEUX CONDITIONS SUIVANTES :S :

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TC technician for help.

CAUTION

Never try to open or repair the device yourself. Any changes or modifications not expressly approved by TrackMan A/S could void the user's authority to operate the device.

WARNING: RADIATION HAZARD

Radiation Safety Warning.

This device radiates a low level of microwave electromagnetic radiation from the front window and top when in use. The radiated power is significantly lower the international safety standards for microwave frequencies. However, the user should maintain a minimum distance of 20 cm from this device during operation.



READ THIS INSTRUCTION BEFORE USING YOUR TRACKMAN

THIS INSTRUCTION DEALS WITH IMPORTANT REGULATORY- AND SAFETY INFORMATION.

Safety instructions – save this for future use

1. Use the only supplied adapter – indoor.
2. Plug in the adapter to household outlet of 100-240volt ac (50-60Hz) only and use the adapter only for the intended use.
3. Always unplug the adapter from the mains supply after use.
4. Do not cover the adapter or appliance during use.
5. Cleaning and maintenance instruction see this user manual.
6. The user should maintain a minimum distance of 8 inch from this appliance during operation.
7. The appliance is splash-proof and designed to handle rain. Clean camera lens, if needed.
Clean the appliance and adapter with a dry cloth after use, if needed.
8. It's strictly prohibited, under any circumstances, to try to separate or repair the appliance and/or adapter personally due to the consequential risk of personal injury. Without specialist tools is it not possible to guarantee the safety of these products during use.
9. Always examine adapter, appliance, cord and plug for damage before use. If the supply cord is damaged, it must be replaced by the manufacturer, his service agent or a similarly qualified person to avoid a hazard.
10. Do NOT use the B1 without protective foam cover.

CLEANING AND MAINTENANCE

UNPLUG THE ADAPTER AND LET IT COOL DOWN FOR 10 MINUTES.

Always remove DC-plug from the appliance before cleaning.

Appliance and adapter can be cleaned using a wet cloth or sponge having a mild cleaning detergent.

BATTERIES

WRONG USE OF BATTERIES CAN RESULT IN OVERHEATING, LEAK OR EXPLOSION. PLEASE FOLLOW THESE INSTRUCTIONS TO ELIMINATE ANY DAMAGE:

- Do not open, disassemble or visual check a battery.
- Do not crush or puncture a battery.
- Do not short circuit battery or subject the battery for liquids or high temperatures: Above 112°F during use.
- Stop using the battery, if damaged or leak is observed.

	APPLIANCE	ADAPTER
NAME	B1	FSP Switching Power Adapter
MODEL NO.	TMB4A	FSP065-REC2
SIZE	330x340x75mm (hxxxd)	45x105x30mm (hxxxd)
WEIGHT	<3 kg	<0.5kg
INPUT VOLTAGE	19VDC, 65W maximum during charging	100-240Vac, 50-60Hz 75W maximum during charging
OUTPUT VOLTAGE	-	19VDC maximum 65W
DATA CONNECTION	WiFi, 2.4GHz 802.11 b/g USB 2.0 high speed (For service only) Gigabit Ethernet	- - -
ENVIRONMENTAL DURING USE	40-104°F 95% humidity	32-104°F 90% humidity
ENVIRONMENTAL DURING STORAGE	-4-130°F 95% humidity	-4-130°F 95% humidity

Subject to continuous changes and improvements reserved

