


G61 Quick Guide

Your Phone



Key

- Back** - Back to the previous screen or exit
- Home** - Return to the Home screen
- Recent** - Open a list of recent applications
- Volume** - Volume up/down. Continuously press to turn to silent and vibrate mode. Adjust the call volume. Adjust the music playback volume.
- Power** - Press short to turn on/off the screen display. Press 3s to turn on/off the phone. Press 15s to restart the phone.

Open the Recent Applications

Press the Recent key to open and quick access the recent applications. Slide left or right in the list to delete the applications.

Take a Screenshot

Press the power and volume keys at the same time to take a quick screenshot for the current page.


Call Mute

Press the power or volume key to turn off the ring when there is a call.

Insert SIM Card and Micro-SD Card

Note

Please power off the phone and pull out the battery before you are ready to insert the SIM card. If not, the SIM card might be damaged.




Insert SIM Card

The phone can support double SIM cards. The card slot will support a 3G (WCDMA) or 4G SIM card (FDD_LTE), but one SIM card can use 4G networks only.

Insert Memory Card


This phone supports external Micro-SD card (TF card) and can be extended up to 64GB. The memory card should be inserted into the card slot correctly to the position line. Please follow the picture shown above.

Home Screen




Notification Bar

Slide down the notification bar to read detail notice. Slide up or press the Back Key to get the notification bar back.



Steps to Turn On Date Connection Using the Notification Bar



Status Icon

Icons	Functions
	Signal strength
	"H" HSPA connected, "3G" WCDMA connected, "G" GSM Connected
	"4G" LTE FDD connected
	The bars indicate the battery level.
	Silent mode activated.
	Vibrate mode activated
	Flight mode activated.
	Call in progress.
	Call on hold.
	You have a missed call.
	New SMS or MMS.
	New Email.
	Connected to PC.
	The alarm clock is activated.
	There is no SIM card in the phone.
	The headset is plugged into the phone.
	Error occurred or caution required.

FCC RF Exposure Information and Statement

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: Mobile Phone (FCC ID: SG7201707G701) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on - line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested simulation typical 10mm to body. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.