80mm

110mm

Top spread — Page 3 (left) and Cover (right)

➤ **Receiver Connection**

Insert the nano receiver to the USB port of your computer, pushing the ON button on the bottom of the mouse, and the receiver will detect the device automatically, plug and play.

➤ **Rebuilding up the Connection between Mouse and Receiver**

If your mouse cannot work normally, you can try to build up the connection again between mouse and receiver, as following steps:

1. Take out the nano receiver from computer and insert again, it will detect automatically for about 15 seconds.
2. Keep the mouse in ON mode.
3. Keep the effective distance within 10CM between the mouse and receiver
4. Press the left button and right button at the same time for about 1-3 seconds, then release it. The connection is being built for about 10 seconds.
5. If you cannot build up the connection in 10 seconds, please repeat the above steps.

➤ **Debugging Tips**

- Check the receiver if it s connected to the USB port.
- Check the ON/OFF button if in ON mode.
- Check the effective distance between mouse and the receiver, and shorten it.
- Rebuild up the connection between the mouse and receiver.

CE ♻ ⟳ 🗑

Vertical Mouse

User Manual

## Bottom spread — Page 1 (left) and Page 2 (right)

Thank you for choosing this wireless office mouse. Please read user manual carefully when using this product.

➤ **Contents:**

- Wireless Vertical mouse X1
- User manual X1
- USB nano receiver X1

➤ **Button Function:**

1. Left click
2. Right click
3. Scroll wheel
4. DPI cycle
5. Forward
6. Backward
7. ON/OFF switch
8. USB nano receiver

➤ **Features**

- Vertical shape
- Rechargeable 2.4GHz Wireless Mouse
- 500mA Built-in Battery
- For home user and business office

➤ **Installation**

Plug the USB nano receiver to the USB port in the computer, after detecting successfully it will work normally.

LED Light

Press the forward key and backward key at the same time for 3s to turn on or turn off the light.

➤ **Specification**

DPI	1000/1200/1600
Report rate	125Hz
Working Vollage	5V
Working current	≤ 500mA
Compatible system	Windows 8/10/mac OS

FCC Caution：

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.