

Thank you for choosing our gaming mouse. Please read the user manual carefully before and when you use this product.

Package content Type-c cable x1 6.5g weights x2 Manual x1 ه @CD (optional) x1



① Leftbutton ② Flight button 3 Saral wheel ④ □Plbutton (5) Forward 6 Backward

⑦ EPIndicator light 8 Pushbutton for Nano receiver tray

Nemon

Remark: The indicator light is off for the first level of DPI, one column of green light will be on for the second level of DPI, two column of green light will be on for the third level of DPI, etc.

Features

- Ambidextrous design for both left and right hand users.
 Personalized weight and balance tuning with weights.
 Chargeable mouse with Li-polymer battery, 500 mA.
 8 customized buttons and on-board memory.

Mouse Usage

Connect the mouse with your computer by USB port,it can work normally after detecting finished. If needed,you can set the button functions as followings.

Program (only for wireless mode)

Push the power button on the bottom of mouse, long press left, scroll wheel and right buttons until the Blue LED light of mouse flash, then insert the dongle to the USB of computer, after successfully connected, the mouse can work.

Driver setting

 Installation
 Download the driver from www.deluxworld.com or the CD in the package, install the driver.

Note: Please make sure this mouse is already connected to computer when setting the functions in the driver.

2. Settings

Please remember to click "Apply" to activate your settings, and you can click "Reset" to restore factory default settings. Click any profile, set the functions, choose configuration, and click "Apply", the settings will be saved on board memory, 3 profiles can be saved at maximum.

2.





These settings can be customized as below: DPI, X/Y axis sensibility, Polling rate, Pointer Speed and ACC.

Key settings



These functions can be customized as below. Click, Menu, Scrolling Forward, Backward, Scroll up., Scroll down, Scroll left, Scroll right, Double click, Fire key, Assign a shortcuts, Select macro, Function off, DPI, Multimedia, Windows, Basic function, Advanced function. There are multiple choices under DPI, Multimedia, Windows, Basic function, Advanced function menu

Light settings

3.



Brightness, speed and color can be customized, you can change the color by adjusting the RGB value or drag the cursor on the

4.

Macro Settings



Click and type the name under "Macro Name" to create a macro command, click "Record" button and all your keystrokes and button presses will automatically register on the macro screen. When you finish recording your macro commands, click "STOP" button to finish. The Macro session allows you to input the delay in-between commands. In "Record delay" the delay in-between commands in "Record delay" the delay in-between commands are registered as how it is entered. The "Record delay" uses a predefined time (expressed in seconds) as the delay, And und "No delay" omits all the pauses in-between keystrokes and button presses.

The "Insert" button allows you to put in additional keystrokes, button presses or time delays either before or after the selected command. A new display window will appear beside the list of macro commands. You may add in a new set of macro commands by clicking the button on the keystroke menu, or input time delays on the duration time field using the delay menu.

Caution



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can adalate ratio frequency energy and, if not installed and used in accordance with the instructions, any cause harmful interference to adia communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does couse harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help
 This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference and (2) this device must accept any interference received, including interference received, including interference received.