


XWAVE™ Bluetooth® Speaker


echo 6 / echo 10 Owner's Manual

Front View



Back View

1.



3.5mm
AUX Input

Mini USB
5V DC IN

POWER ON/OFF
SLIDING SWITCH

POWER ON/OFF SWITCH

POWER ON/OFF SLIDING SWITCH

MINI USB 5V DC IN Recharging port

3.5mm Audio Input port

For connecting devices not Bluetooth compatible.

SPEAKER OPERATION

4.VOLUME (+)

- **PRESS & HOLD TO INCREASE VOLUME**
Red light flashes for each step of volume increase.
Red light flashes 5 times when maximum volume reached.
- **PRESS BRIEFLY to advance to next song**
(Bluetooth mode only).
In Bluetooth mode, volume can be controlled both by the speaker and the Bluetooth device.

3.PLAY/PAUSE (⏮)

- In Bluetooth® Mode press briefly to play or pause.
- In AUX Mode, press briefly to play or mute.

2.SPEAKER ACTIVATION (⏻)

Operation/Standby/Pairing/Answering

- **SPEAKER ON:** Press ⏻ 1 second, light will flash slowly.
- **BLUETOOTH® PAIRING:** Press ⏻ second time 1 second.
Quick flashing blue light indicates pairing mode is on.
Speaker beeps twice and flashes slowly when successfully paired.
- **SPEAKER STANDBY:** Press ⏻ 2 seconds. Blue light turns off.
- **INCOMING CALL:** Press briefly ⏻ to answer or hang up.

5.VOLUME (-)

- **PRESS & HOLD TO DECREASE VOLUME**
Red Light flashes for each step of volume decrease.
Red Light quick flashes 5 times when minimum volume reached.
- **PRESS BRIEFLY to return to previous song**
(Bluetooth mode only)
In Bluetooth mode, volume can be controlled by speaker and Bluetooth AUX Device.

6.BATTERY POWER INDICATOR (🔋)

- Slow flashing red light indicates sufficient power
(Over 20% of full capacity)
- Quick flashing red light indicates low power.
Less than 20% remaining. Speaker needs recharging.
- Speaker shuts off when less than 3.3 volts.

Mode Priority

AUX Audio cable connects speaker to auxiliary devices (such as smart phones, tablets, laptops, etc.).

Connect AUX audio cable to 3.5mm jack.

When AUX audio cable connected to speaker, AUX device is recognized as default or highest priority mode.

Bluetooth Multi-link Pairing

To activate a second Bluetooth device, press pause on the first Bluetooth device. Pair second Bluetooth device with Bluetooth speaker.

After second Bluetooth device has been paired, press play on the second Bluetooth device. Press play on whichever Bluetooth device you wish to use.

To use Multi-link Pairing function, both Bluetooth® devices need to be paired directly with the speaker separately.

Sleep Mode (extends battery run time)

- Speaker in sleep mode when signal not detected for 5 minutes.
- Press & Hold SPEAKER ACTIVATION button ⏻ 2 seconds to wake speaker.

XWAVE™ Bluetooth® Speaker

echo 6 / echo 10 owner's Manual

Overview

Thank you for purchasing the XWAVE™ Portable Wireless Bluetooth® Speaker with rechargeable battery.

Enjoy music from your smart phone, tablet, laptop, or other Bluetooth-enabled device.

AUX cable permits speaker uses with both Bluetooth-enabled devices and non-Bluetooth devices.

Important Safety Instructions

- Read and follow all instructions.
- Clean only with dry cloth.
- Do not use speaker near splashing or dripping liquids.
- Do not place any objects on top of speaker.
- Protect the power cord from being walked on or pinched.
- Unplug the speaker during lightning storms or when unused for long periods of time.
- Never open speaker outside case.
- Do not block ventilation sources.

Service

- Do not attempt to change the rechargeable battery.
- Refer all servicing to qualified personnel.
- Servicing is required when
 - Speaker has been damaged in any way, such as power cord or plug damage.
 - Liquid has been spilled on the speaker or objects have fallen into the speaker.
 - Speaker has been exposed to rain or moisture
 - Speaker does not operate normally, or has been dropped.
- Specifications are subject to change without notice.
- 1-year Limited Warranty covers materials and workmanship.
- 1-year Limited Warranty does not cover misuse, abuse, normal wear and tear.

1 Year Product Guarantee

| Distributor / Dealer | Purchase Date |
|----------------------|---------------|
| | |

Warning

- Never lubricate any part of speaker.
 - Never place the speaker on other electrical equipment.
 - Keep speaker away from direct sunlight, flame, or heat.
 - Always have easy access to the power cord, plug, or adapter in order to safely and easily disconnect the speaker from the power source.
- ⚠ Do not leave speaker in direct sunlight, near any heat sources, or inside enclosed vehicle.**
- Exposure to extreme temperatures can cause damage to both the Li-on battery and the speaker itself.**

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

changes / modifications not approved by the responsible party could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

XWAVE™ Bluetooth® 3.0 Speaker works with smart phones, tablets, laptops, music players, and other Bluetooth® devices.

AUX cable permits speaker uses with both Bluetooth® devices and with non-Bluetooth® devices.

