



# Insynctive BRIDGE

## QUICK START GUIDE



### WHAT'S INCLUDED:

- PELLA INSYNCTIVE BRIDGE
- NETWORK CABLE
- POWER SUPPLY AND CORD
- QUICK START GUIDE

### WHAT'S REQUIRED:

- ONE OR MORE PELLA INSYNCTIVE PRODUCTS (sold separately).
- STATUS INDICATOR (OPTIONAL – SOLD SEPARATELY): Lights indicate status of Pella Insynctive SENSORS. Or you can use a compatible security or home automation system.
- ROUTER WITH LAN PORT (sold separately, not available through Pella): Required for receiving firmware updates or for using the Pella Insynctive App (coming soon).

### CONNECTING TO HOME AUTOMATION?

For a list of compatible home automation systems and instructions on how to enroll and sync your devices, visit [Pella.com/Insynctive](http://Pella.com/Insynctive).

### SYNCING PRODUCTS MANUALLY?

Refer to the Quick Start Guide included with your Insynctive SENSOR or other Insynctive device(s), or visit [Pella.com/Insynctive](http://Pella.com/Insynctive) for instructions on how to sync your devices to BRIDGE.

### NEED HELP?

For instant access to warranties, troubleshooting information and videos, visit [Pella.CustHelp.com](http://Pella.CustHelp.com) or call 855-473-5524.

## ⚠ WARNING

**Failure to adhere to the warnings below may result in death, serious injury and/or loss of valuables.**

- Pella Insynctive products are not 100% reliable for a variety of reasons (see Product Guide for more information). Therefore, Pella Insynctive products should not be relied upon in situations where life, safety and/or protection of valuables are solely dependent on their function. Test each product at least once per year to help ensure proper operation.
- BRIDGE may be connected to a non-Pella product, such as a compatible home automation system. All systems are subject to compromise or failure to warn for a variety of reasons. Review and comply with the information for the system that BRIDGE is connected to.
- Pella Insynctive products are not a substitute for careful adult supervision of children.
- Keep small parts out of the reach of children. If small parts are swallowed, immediately seek medical help.
- Use only Pella-provided power cord and supply. Failure to do so may result in damage to BRIDGE that would not be covered by the warranty.

Read the complete Product Guide for additional warnings and information.

### FCC Compliance and Industry Canada

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit from the receiver.
- Consult the dealer or an experienced radio/TV contractor for help.

Changes or modifications not expressly approved by Pella Corporation could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of this device.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS. L'opération est soumise aux deux conditions suivantes: (1) cet appareil ne peut causer d'interférences, et (2) cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

FCC ID: SO7-208B0000  
IC ID: 11009A-208B0000



This Quick Start Guide is intended only to provide an overview of the product and its use. Before using this product, read the complete Product Guide and warnings. The Product Guide contains additional terms, conditions and policies that govern your use of the product, and by using the product, you consent and agree to be bound by such terms, conditions and policies.

Visit [Pella.com/Insynctive](http://Pella.com/Insynctive) for complete Product Guide and warnings, instructional videos and other Pella® Insynctive® quick tips.



### 1. Get Started

- Plug network cable into BRIDGE and into router.
- Using provided power supply and cord, plug BRIDGE into an electrical outlet.

**NOTE: Light on BRIDGE will turn green, indicating startup, then cycle through a color wheel while checking for and updating firmware.**

### 2. Sync Pella Insynctive Devices to BRIDGE

- Refer to the Quick Start Guide included with your Insynctive product(s), or visit [Pella.com/Insynctive](http://Pella.com/Insynctive) for instructions on how to sync with BRIDGE.