

Operating Manual for the radio control system

- 1, The radio control system is 4 channels. For rudder, elevator, motor control and throttle, respectively.
- 2, The transmitter needs 8 AA dry batteries. After you install the batteries, you can turn on the transmitter, the green will come on. If the voltage of battery is too low, the transmitter will beep automatically, then you must install new batteries.
- 3, When you bush the joystick on the right horizontally, the rudder will turn in response to your action. It will make the plane turn right or left. When you push the joystick vertically, the elevator will turn as will. It will make the plane climb or dive.

The function of the system:

Transmitter:

Model: E-FLY TX 100

Work voltage : +12V DC Frequency:72M

Receiver:

Model: E-FLY RX 100

Work voltage : +5V DC Frequency:72M

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.