


Ever Sparkle Technologies Limited

Controller Operation Procedure

A. Below is the Control button layout drawing



B. How to operate the buttons

1. [Power/OK] button

- i. Press once to power on the controller. The default setting of turn off time is 15 minutes. The unit will be turned off as per the Timer setting.
- ii. To turn off the controller when timer has not been reached, press and hold the [Power/OK] for 3 seconds.
- iii. Use [Up] / [Down] buttons to adjust the power level. There are total 5 levels can be set.

Remark: When reaches to level 5 and press the [Up] button, the level 5 LED will be flashed with 0.5 sec interval. When reaches to level 1 and press the [Down] button, the level 1 LED will be flashed with 0.5 sec interval.

When the temperature has been raised to a comfortable level, press the [Power/OK] button once to fix the temperature.

Question: - How to operate on App?

- iv. The temperature set by above item 'iv' will be released when [Up] or [Down] button is pressed.
- v. The temperature set by above step 'iv' will be stored in the memory. When the unit has been powered on again without pressing the [Up]/[Down] buttons, the same temperature setting will be applied.
- vi. The maximum temperature will be set at 50 degrees C.
- vii. **To further increase the temperature to above 50 degrees, press and hold the [Up] button for 5 seconds.**
- viii. **The temperature will not be increase when reaches 60 degrees C.**

2. Down button

Each press on the button will reduce the power by one step.

3. Level Indicator (LEDs)

To indicate the power level.

4. Up button

Each press on the button will increase the power by one step.

5. Timer button

- i. Default is 15 minutes when power on.
- ii. Press once to switch to 30 minutes.

- iii. Press one more time to switch to 60 minutes.
- iv. When pressing the Timer button continuously, it will be cycled between 15 minutes to 60 minutes.

6. FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

End