Mobile Appearance picture



Manufacturer: **ZTE Corporation** Model: 22317

	able of Contents	
	oblie Appearance picture	
1.	Quick start	. 6
	Install SIM card	
	Install T-flash card	. 7
	Installing Battery	. 8
	Battery Charging	. 9
	Battery Safety	. 9
	E-waste/Recycle your phone	. 9
	Care and Maintenance	10
2.	Menu functions	12
	Contacts	12
	Message	12
	Call log	12
	Camera	12
	Gallery	13
	FM Radio	13
	Music	13
	File manager	13
	Bluetooth	-
	STK	14
	Calendar	
	Alarm	
	Calculator	
	Settings	
	Browser	-
3.	Accessories	
4.	FCC Regulations	18
5.	SAR	20

Foreword

Honorific mobile phones user, thank you for choosing our mobile phone!

Our cellular phones is according with the communication industry standards of PRC, and also according with the standards of European, and are approved for GSM networks.

Your phone may be used internationally with various networks depending on your roaming arrangements with your service provider.

To use this phone you must subscribe to a GSM service from a provider. We have included many features in this device but their function depends on the features available with your subscribed wireless network. Please contact your service provider for more information.

We strongly recommend you carefully read and understand this manual before using your phone in order to keep it under best conditions for your effective usage and utmost satisfaction.

Safety

Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.

As a general rule, always switch off your phone wherever the use of a phone is prohibited.

Use of your phone is subject to safety measures designed to protect users and their environment.

Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.

Do not expose your phone to extreme temperatures lower than - 10°C and higher than + 55°C.

Please note that the ambient temperature range for normal charging of mobile phones is $0 \,^{\circ}\text{C} \sim 45 \,^{\circ}\text{C}$. Do not charge at an ambient temperature below $0 \,^{\circ}\text{C}$ or above 45 $^{\circ}$ C, as this will result in reduced battery performance and reduced life. Charging for too long at too high or too low ambient

temperatures can damage unfilled or swelled batteries, and there is a risk of battery explosion

The physicochemical processes created by chargers impose temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures.

Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested).

Electrical safety

Only use the chargers listed in the manufacturer's catalogue. Using any other charger may be dangerous; it would also invalidate your warranty. Line voltage must be exactly the one indicated on the charger's serial plate.

Aircraft safety

When traveling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs. Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network.

Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations.

Explosive materials

Please comply with warning signs at petrol station when personnel asking you to switch your phone off. You will need to comply with radio equipment usage restrictions in places such as chemical plants, fuel depots and at any location where blasting operations are under way.

Electronic equipment

To avoid the risk of demagnetization, do not let electronic devices close to your phone for a long time.

Electronic medical equipment

Your phone is a radio transmitter which may interfere with electronic medical equipment or implants, such as hearing aids, pacemakers, insulin pumps, etc. It is recommended that a minimum separation of 10mm be maintained between the phone and an implant. Your doctor or the manufacturers of such equipment will be able to give you any advice you may need in

this area.

Hospitals

Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.

Road safety

Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.

Distance of operation

This phone model has been tested and meets radiofrequency exposure guidelines when used

As follows:

Against the ear: place or receive a phone call and hold the phone as you would a wire line telephone.

•Body worn: when transmitting, place the phone in a carry accessory that contains no metal and positions the phone a minimum of10mm form your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the phone at the ear, position the phone a minimum of 10 mm from your body,

Data operation: when using a data feature, position the phone a minimum of 10mm from your body for the whole duration of the data transmission.

Environmentally friendly disposal



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

1. Quick start

Keypad Explain

Кеу	Function description		
Left key	In idle screen, press the key to enter notices		
Right key	In idle screen, press the key to enter Contacts app directly.		
Answer key	Answer the incoming call, and in the idle screen, press the key enter the call history direct.		
Power on/off key	Reject the incoming call, and in the home screen,long press to bring up the shutdown menu.Other screens, back to home screen or delete the input characters.		
Navigation key	Up/Down/Left/Right move the high light. In idle screen,up key to enter shortcut menu,long press up key to open torch;right key to quick enter camera.		
Center key	Confirm the select to enter function.In idle screen,long press to enter Google assistant.		
Number key	Input the corresponding character		

* kev	Dial pad input star character, in idle	
NCy	screen, long press to lock the phone.	
# key	Press to input # character	

Install SIM card

 Locate the SIM card slot, and then insert the SIM card with its gold contacts facing down and its cut-off corner facing out of the card slot as shown in the diagram.

·Slide the SIM card completely into the slot.

Note :

1. Keep SIM card out of children's touch.

2. Any abrasion or folding could easily damage SIM card, so please be extremely careful when you insert, Remove and preserve it.

Please make sure that you have cut off the power supply and have taken out battery before you remove SIM card.

Install T-flash card

1. First switch off the phone and remove the battery.

2. Push the metal card holder toward the bottom of the phone and lift the released end of the holder.


3. Place the memory card into the holder with the metal contacts face down and push the holder until it locks into place.

Note:

1.To avoid damaging memory card, please do not plug memory card fast or frequently.

2. Please regularly backup information in the cards on other equipment when you use Cards like T-flash! Improper use or other uncertain factors may cause the

damage or loss to the content in the cards.



Installing Battery

Align the battery chip with the metallic salient point in battery jar, insert the battery until it is inserted into the battery jar. Slide battery cover into back of the phone until it is locked.



Battery Charging

Insert the charger on the charging interface.

When electric quantity is too low, the phone will power off automatically. Please don't make the battery in the status of not enough electric quantity for a long time; otherwise it may damage the battery quality and service life. Please don't charge the battery for a long time.

Prompt: In order to ensure normal operation of the phone, please make sure to use the designated charger.

Battery Safety

Do not place the battery in fire; follow local laws and ordinances in disposing used battery.

Check the model number of the charger before using it to charge the mobile.

Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger.

Return waste and used batteries to the supplier or specified recovery site.

CAUTION!

Risk of explosion if an incorrect type replaces battery.

E-waste/Recycle your phone

You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipment's at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment.

1 Instructions for disposal of products

 a) At the end of their life, should drop used electronic products, batteries, and packaging materials in the nearest disposed products cans or collection center

b) Should divide the packaging materials according to corresponding waste disposal options and sort for recycling.

c) Battery should be removed from the product for recycling.

2 Prohibition for disposal of equipment

a) Never dump E-wastes in garbage bins or municipal solid waste stream.

3 Information on the consequences of improper handling, accidental breakage damage and improper recycling of the end of life product.

a) If batteries are not properly disposed of, it can cause harm to human health or the environment.

b) If the battery terminals are in contact with metal objects, it may cause a fire.

Care and Maintenance

Maintenance of battery

 Your device is powered by a rechargeable battery. It is necessary to have the battery charged when it is going to wear out. To prolong battery life, new battery need to run out of power for the first charge.

 Unplug the charger from the electrical plug and the device when not in use. Do not leave fully a charged battery connected to a charger over a week, since overcharging may shorten its lifetime.

•Do not expose your phone to extreme temperatures lower than 2°C and higher than 50°C.

· Use the battery only for its intended purpose and avoid

short-circuiting. Accidental short-circuiting can occur when a metallic object causes direct connection of the positive (+) and negative (-) terminals of the battery.

•Do not use damaged battery.

 Leave the battery in hot or cold places will reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.

•Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations.

Care of maintenance of your device

The suggestions below will help you protect your warranty coverage.

•Keep the device and accessories out of the reach of small children.

•Keep the device dry. All types of liquids or moisture will corrode electronic circuits.

•Do not store the device in hot areas. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.

•Do not attempt to open the device other than as instructed in this guide. Non-professional handling may damage the device.

•Do not use harsh chemicals or strong detergents to clean the device.

•Use only the supplied or an approved replacement attachments, for the unauthorized ones could invalidate the warranty of maintenance.

2. Menu functions

Contacts

The Phone for your well-prepared high-capacity phone storage space. You can use the phone's contacts feature to save the contact name, number .

Quickly find contacts, use the search menu on the top of the contact list.

Message

Message service is a network dependent function, which allows you to send, receive and edit all kinds of messages. Please contact the network operator for more details.

Edit a new message, save or send it to the recipient.

Call log

This phone can record all received, dialed and missed calls as well as their call time. Only when related function is supported by network and phone is switched on and in network service area, it can record the answered and missed calls. Call records may be accessed by pressing the answer key from standby or from the main menu.

In the call history list, press the left/right navigation key, switch to Display list of all /missed/dialed/received calls.

Once on the call records list, press the Answer key or the Center key to make a call; press the Right key to view the details of current call record.

Camera

Your phone is fitted with camera allows you to take photos whenever possible. You can store the pictures in phone or SD card.

Press the center key to take photo, press the left/right navigation key switch to video record.

Gallery

You can use Gallery to view pictures that you've taken with Camera, downloaded, or copied onto your SD card or USB storage. You can perform basic tasks(zoom etc) on pictures and set them as your wallpaper. You can also share your pictures with friends, via facebook,messages,Bluetooth, or by uploading them to the Facebook and YouTube web sites.

FM radio

FM radio is supported by the phone. You just pull the bottom of the antenna and no need plug in your headphones to listen to FM Channel

Note: Quality of radio subscription is possible influenced by environment like indoor or under shield. You can improve this situation as following: stand closer to the window, adjust the position of earphone line or adjust the channel manually.

Music

Your music is organized into four categories: Playlist, Artists, Albums, Songs. Select a category to view the lists within each. Once in a category, keep selecting until you reach the music you want to play.

File manager

In document management, you can open files in the Phone or Memory card, you can select file or folder to view.

To transfer files between your phone and your computer, you need to change the status of Settings-Storage-USB Storage to Enable.

Bluetooth

The phone supports Bluetooth functions, you can establish a wireless connection between the phone with other compatible devices, and data transmission, you can establish a wireless connection between devices in the phone with a distance of up to 8 meters. Bluetooth connection may be interference by obstacles, such as walls or other electronic device.

1. Enter the setting menu, Turn on the Bluetooth, idle screen will display Bluetooth icon in the status bar.

2. Before using the phone as a Bluetooth device, you need to pair the phone with the target device as follows:

-Make sure your phone has Bluetooth enabled.

-Select "Nearby Devices." Bluetooth devices within the range of the phone will start scanning.

-Select the device you want to pair, confirm on the matching machine to complete the pairing.

You can use Bluetooth to share the pictures, videos or music files with family and friends.

STK

The phone supports value-added services provided by the SIM, different network operators to provide different types of services, and the menu is shown only if your SIM card supports. The name and contents of the menu depend on the available services. Ask your network availability, price, and information on the SIM card service operators Advisory.

Calendar

Choose to enter the calendar, the screen will display the system date on the calendar month, and have a background box marked the current date.

Alarm

You can use the phone as alarm clock, this feature allows you to set time arrives, make the phone ring or vibrate to remind issue. When the alarm is turned on state, the alarm symbol is displayed on the top of the screen.

Calculator

Into the calculator, the calculator interface:

Press 0 - 9 number keys to enter the number to be calculated, press the navigation key to select the location on the screen corresponding to add, subtract, multiply and divide symbols for computing.

Settings

Network&connectivity: include Airplane Mode, Mobile network&Data, wifi, Bluetooth, SIM manager, call setting etc. You can enter the corresponding menu to operate.

Personalization: include sound, display, notices, date&time, language,input methods. You can enter the corresponding menu to operate.

Privacy&Security: include screen lock, app permissions etc. You can set screen lock and protect your phone from information disclosure here.

Storage:include change storage location menu and view detailed usage of internal storage and SD card menu.

Device:include device information, downloads, battery, accessibility. You can enter the corresponding menu to operate.

Account: From here, you can sign the KaiOS account, and if your phone lost, you can use the "Anti-Theft" function to find your phone.

Factory reset: To restore your phone's factory settings and delete all your data, press the navigation key to open the application list, select Settings, scroll right to device, and select Device Information> Reset Phone.

Browser

The Internet is the combination of wireless communicate -on and Internet application platform that enables you to get rich by phone and ecommerce and other Internet information resources application.

Note:

1. Your ISP may not support some features, in order to

ensure the normal operation of the browser, make sure your SIM card is supported and open Internet access. 2. If you browse the web, you need to charge fees related to traffic.





3. Accessories

Use only batteries, chargers, and accessories approved by the manufacturer with this device. Use of any other types will invalidate the warranty and may be dangerous. Check with your dealer for available accessories. You may opt to buy:

Charger Plug, charger cable

Charger plug used to connect with the charger cable for charging on wall outlets. Also you can use the charger cable to connect with the other devices such as the personal computers to charge the phone.

Charging time is about 2 to 3 hours. The charging condition is displayed on screen. You may use your phone while charging.

Earphone

A mini, practical, hands-free device; you can use its button to answer and end calls. Some models may also come with a volume control knob.

Do not plug or unplug the earphone when connecting dialed or incoming calls.

Please to adjust the incoming call alert volume to the felicitousness before you plug in the earphone.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

4. FCC Regulations

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC ID: SRQ-ZTEZ2317

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

---Reorient or relocate the receiving antenna.

---Increase the separation between the equipment and receiver.

---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

---Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

This device was tested for typical body-worn operations. To comply With RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna.

Third-party belt-clips, holsters, and similar including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

5. SAR

This wireless phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 1.315W/kg and whe n properly worn on the body is <u>1.348W/kg</u>. This device was tested/or typical body-worn operations with the back of the handset kept 1 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1 cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

6. Technical Specifications

Battery: 4.2 Li-on

For the network:

2G:850/900/1800/1900Mhz

3G: 850/1700/1900/2100Mhz

Battery refer to the following table:

Battery	Battery	Talk	Standby
Туре	Capacity	time	time
Li-battery	1000mAh	4hours	200hours

Battery model: 5C-1000

Notice:

The actual condition for mobile phones using has the relation to the network of the local environmental conditions, SIM card and the way using.

Warning:

For the consequences result by violating the following recommendations or using mobile phones In accurately, the manufacturers has no responsibility.

Explain: If relate to the upgrades, without notice. The Company has the right for the final interpretation of this statement.