

0624755




RBW 10 MHz Delta 1 [T1]
*VBW 3 MHz 0.00 dB
SWT 50 ms 0.000000 s

Ref 0 dBm

*Att 20 dB

Duty Cycle

1 PK *
CLRWR



Marker 1 [T1]
-59.13 dBm
50.000000 ms

SGL

$$= \frac{2(0.5) + 8(1) + 11(1.5)}{100}$$

$$= \frac{1 + 8 + 16.5}{100}$$

$$= 0.255 //$$

Average Factor

$$= 20 \log 0.255$$

$$= -11.9 \text{ dB}$$

Center 389.91 MHz

5 ms/

0624955




RBW 10 MHz Delta 1 [T1]
*VBW 10 MHz 0.12 dB
SWT 200 ms 101.000000 ms

Ref -20 dBm

Att 10 dB

1 PK *
VIEW



SGL

Center 389.91 MHz

20 ms/

0624955



RBW 10 MHz
* VBW 3 MHz
SWT 20 ms

Ref 0 dBm

* Att 20 dB

1 PK *
CLRWR



SGL

Center 389.91 MHz

2 ms/

0624955




RBW 10 MHz Marker 1 [T1]
*VBW 3 MHz -17.23 dBm
SWT 5 s 2.100000 s

Ref 0 dBm

*Att 20 dB

1 PK *
VIEW



Center 389.91 MHz

500 ms/