




RBW 3 MHz      Delta 1 [T1 ]  
\*VBW 3 MHz      0.18 dB  
SWT 100 ms      50.000000 ms

Ref -20 dBm      \*Att 0 dB

1 PK \*  
CLRWR



B

SGL

Duty Cycle  
= [1(0.7) + 12(1.36)] / 50  
= (0.7 + 16.32) / 50  
= (17.02) / 50  
= 0.34

Average Factor  
= 20 log (0.34)  
= -9.4dB

Center 433.248 MHz

10 ms/



RBW 3 MHz

\* VBW 3 MHz


SWT 30 ms

Ref -20 dBm

\* Att 0 dB

1 PK \*  
CLRWR

\*  
B  
SGL



Center 433.248 MHz


3 ms/



RBW 3 MHz      Marker 1 [T1 ]  
\* VBW 3 MHz      -45.23 dBm  
SWT 1 s      616.000000 ms

Ref -20 dBm      \*Att 0 dB

1 PK \*  
VIEW



Center 433.248 MHz


100 ms/



RBW 3 MHz  
\* VBW 3 MHz  
SWT 400 ms

Ref -20 dBm \*Att 0 dB

1 PK \*  
CLRWR



Center 433.248 MHz

40 ms/