


portable speaker

USER MANUAL



EN



DC 5V: Plug the Micro USB cable to the speaker and connect other end USB port to the power source. (DC 5V)

USB slot: Used to read the Mp3 files.

TF slot: Used to read the Mp3 files.

Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause. Press and hold to change the RGB flame light mode.

M: To change mode during USB/TF, Bluetooth, FM and Aux-in mode. Press and hold for TWS function.

PREV: USB/TF/Bluetooth/FM mode: press to move to previous FM channel / track. long press to decrease the volume.

NEXT: USB/TF/Bluetooth/FM mode: press to move to next FM channel / track. long press to increase the volume.

POWER ON/OFF: Power KNOB, whirling to turn on.

CONNECT TO BLUETOOTH DEVICE

Turn on the unit and switch on your mobile Bluetooth, then search for the speaker model name "BT Speaker" and pair the device. Once device is paired, Bluetooth will automatically connect when unit is turned on subsequently.

TWS: If you have two speakers and both have TWS Function, turn on both units and press any MODE button for a few seconds. Then both speakers will connect automatically.

Note: True wireless stereo function only works in Bluetooth mode.

BLUETOOTH

Turn on the speaker, it will come into the Bluetooth mode directly. After pairing the device, it can play the music, Short Press **▶||** to Play/Pause, press **-** and **+** to Prev and Next. Press and hold the **-** and **+** button to turn down and turn up the Volume.

USB/TF CARD

Insert the U flash memory or Micro-TF card into the USB/TF slot. It will read the MP3 format music automatically. Press **▶||** to Play/Pause, short time press **-** and **+** to Prev and Next, press and hold **-** and **+** button to turn down and turn up the Volume.

FM RADIO

Press **M** to switch to FM Mode. Short press **-** and **+** to the frequency station. Press **▶||** to search the frequency station and record automatically, press and hold **-** and **+** button to turn down and turn up the Volume.

CHARGING

Please use the original charging cable to charge.
Red LED on when charging.

ACCESSORY

Charging cable: 1 piece

SPECIFICATION

- Wireless version: 5.3+EDR
- Speaker driver unit size: 2INCH
- Frequency response: 100Hz-20KHz
- Signal to noise ratio: >=85dB
- FM scan range: 87.5-108.0Mhz
- Wireless range: 10 meter
- Max memory USB/SD: 32GB
- USB charging: DC 5V/500mA
- Battery capacity: 500mAh
- Charging via USB port (PC): 1.5 hours

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference, received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 0 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by C.J Global is under license. Other trademarks and trade names are those of their respective owners.