
Portable Bluetooth® Speaker with LED Lighting and Carrying Strap




Instruction Manual
Please read carefully before use and keep for future reference.

At a Glance



1	OFF/ON	Set the switch to the "ON" position to turn the speaker on.
		Set the switch to the "OFF" position to turn the speaker off.
2	DC 5V charge port	Connect to a USB power source with the included cable.
3	AUX connector	AUX mode. 3.5mm stereo connection for devices with 3.5mm line-out.
4	Display	Indicates which mode the speaker is in.
5	MIC	MIC mode. 6.35 mm input connection for a microphone. The microphone will work in all modes (except FM mode).
6	USB port	USB mode. Load USB memory sticks here.
7	TF reader	CARD mode. Load microSD memory cards here.



8	M/TWS	Press to change the active mode (Bluetooth®, FM tuner, LINE, Music (USB orTF). For TWS function – Press and hold to pair another compatible device.
9	 4≪/-	Press to skip to the previous track during playback.
		Press and hold to decrease the volume.
10	►II /LED	Press to pause or resume playback. Press and hold to turn the LED light on or off.
11	▶►! /+	Press to skip to the next track during playback.
		Press and hold to increase the volume.
12	MIC-VOL	Adjust the microphone level. There are 10 microphone levels.
13	Handle	Flip out the handle for a convenient way to carry the boombox without a strap.

www.emersonaudio.com Page 3 Page 4 www.emersonaudio.com

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.