

Dexatek ΣCasa/SmartCasa

Quick Installation Guide




1. [Smart Gateway](#) [ΣCentral/Smart Gateway](#) [4](#)
- 1.1. [First time to use ΣCentral/Smart Gateway](#) [4](#)
2. [The steps before you add any peripheral](#) [錯誤! 尚未定義書籤。](#)
3. [ΣPlug/Smart Power Plug](#) [1](#)

1. ΣCentral/Smart Gateway

1.1. First time to use ΣCentral/Smart Gateway

5

Follow the instruction on App to set up your ΣCentral
根據 APP 上的指示進行安裝



6

Push the RESET button and **hold for 3 seconds** until the Orange LED flash quickly

• 請按住 ΣCentral 中間鈕 3 秒直到顯示



3

Make sure the bluetooth on your
手機已開啟藍牙

7

Select the WiFi router to be connected

選擇欲連接的 WiFi router



4

Power ON the ΣCentral and place it at
開啟 ΣCentral 並將它放在

8

Switch to [Device] tab, you will see the information of location and weather forecast. Now you can start to add other devices

切換至「Devices」頁面，你將看到位置等資訊



2. ΣPlug/Smart Power Plug

1

Please make sure the distance between Σ Central and other devices is less than 10m

請確認 ΣCentral 與其他裝置保持 10 公尺以內良好通訊距離。



2

Follow the instruction on App to add and pair device


根據 APP 上的指示進行安裝



3

Install the Σ Plug on the power socket where you want


將 Σ Plug 插入準備使用的插座上



43

Pairing with Σ Central for US

Press the reset button and **hold for 3 seconds** until the Blue LED flashes
按住 ΣPlug 上的鈕三秒，直到 LED 燈閃爍為止



5


You will need to enter **PIN code** that combines digits and letters.

1) You can find the PIN code stick on the device

2) OR use default for samples

Default PIN code: 888888

請按照 APP 指示輸入 PIN code



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.