Connect to your network

To use your player, you must connect it to your home network. Typically, customers connect to a wireless (or wired) router rather than directly to a broadband modem. Choose Wireless or Wired setup below, then follow the Guided Setup on-screen to complete the connection process.

Wireless

Wired

Place your player within range of your wireless network. Avoid enclosing your player in a cabinet. During Guided Setup, you may need to enter a password if your network has security turned on,





Use an Ethernet cable (not included) to connect your player to your router.

or



4 | Complete Guided Setup

On your TV

- · Use the remote to follow the on-screen instructions, Your player may download software updates or restart during setup.
- When Guided Setup prompts you to enter your Roku linking code, use your computer to go to roku.com/link, Enter the code that appears on your TV screen and then create a Roku account, if you do not already have one.
- · Once you complete setup, select a channel icon (such as Netflix or Amazon Video On Demand) to view, or visit the Roku Channel Store to add more channels (such as the Pandora Internet radio channel),
- Some Roku channels may require you to activate your Roku player to access their content, Just follow the on-screen instructions when you launch a channel for the



Industry Canada Statement

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two

continuous:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device

Caution: (i) the device for the band 5150-5250 MHz is only for indoor usage to reduce potential for harmful interference to co-(i) the device for the band \$150-2250 MHz is only for indoor usage to reduce potential for hamful interference to co-channel mobile setaletile systems;
(ii) the maximum antenna gain 3.886Bl permitted (for devices in the bands 5250-5350 MHz and \$470-5725 MHz) to comply with the etc. Jr.p. limit, and
(iii) the maximum antenna gain 3.886Bl permitted (for devices in the band \$725-5825 MHz) to comply with the e.l.r. p. limits specified for point-to-point and non point-to-point operation as appropriate, as stated in section A9.2(3).

In addition, users should also be cautioned to take note that high-power radars are allocated as primary users (meaning they have priority) of the bands 5250-5350 MHz and 5650-5850 MHz and these radars could cause interference and/or damage to LE-LAN devices.

IMPORTANT NOTE: IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Basic remote functions

To do this	Press this
Move left or right	∢ or >
Move up or down	▲ or ▼
Scroll left one page at a time	0
Scroll right one page at a time	0
Select an option from a menu	OK OK
Return to previous screen	or (from top of screen)
Return to Roku home screen	•
Start or pause playback	•
Exit playback	← or △
Fast forward	0
Rewind	0
View more options	*
Replay last 7 seconds of video	•

Need help?



To view frequently asked questions, watch instructional videos, access user forums, or to contact Roku customer support, go to roku.com/support.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the finites for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can readled read forequency energy and, if not installated and used in accordance with the instructions, may cause installation and the restrictions are considered and the state of the property of the provider provider and the provider and the instructions, may cause installation. If this equipment does cause harmful interference to be deviced to the provider and the provider a

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

For operation within $5.15 \sim 5.25 \text{GHz}$ frequency range, it is restricted to indoor environment.

LIEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

IMPORTANT NOTE:
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Get started

- ① Plug in
- ② Connect
- 3 Watch





