



#### Note to Adults

To ensure that the child's play is both safe and fun, please go through all operating instructions and safety rules with your child.


#### Battery and Antenna Installation — Transmitter




Unscrew battery cover with a screwdriver (not included).



Install four (4) AA batteries (not included) with polarity (+/-) as shown inside battery compartment.




Close battery cover and tighten screw.




Tighten the antenna into the transmitter.


#### Domino Machines Operation



The power switch is located by the side of the vehicle (as shown). Please make sure it is the ON position when you operate, and OFF position when not in use.




Put in the domino pieces into the side of the vehicle (as shown). Please make sure it is the ON position when you operate, and OFF position when not in use.




As the vehicle moves, the domino pieces will be dropped down one piece at a time. The headlights will blink while this is being performed. The headlights lit up if a piece of domino is successfully dropped.

#### Transmitter Operation



The power switch is located by the side of the transmitter (as shown). Please make sure it is the ON position when you operate, and OFF position when not in use.



To move the vehicle to the left, turn the navigation button anti-clockwise. To move the vehicle to the right, turn the navigation button clock-wise.

#### Safety Tips

NEVER operate your vehicle on the street, through water, sand, thick carpet, or in the rain. If your vehicle gets wet, discontinue use until completely dry.

DO NOT pick up vehicle while in motion.

DO NOT store either unit near a source of heat or in direct sunlight for extended period.

DO NOT drive the vehicle on the table top or other elevated surfaces.

Keep fingers, hair and loose clothing away from the wheels.

Adult supervision is recommended when this vehicle is being operated.

To avoid accidental operation, leave the power switch in the OFF position and remove all batteries when not in use.

#### Quick Tips

When your vehicle begins to lose performance, power or function, it may be time to replace the batteries.

Radio interference may cause your vehicle to run poorly. In the event of interference, you may need to operate the vehicle in another location.

Your vehicle's performance may vary depending on the driving surface.

Point your transmitter antenna up, not downward toward your vehicle. If your vehicle gets too far away, it won't work properly.

**COMPLIANCE WITH FCC REGULATIONS (VALID IN U.S. ONLY)** THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION OF THIS DEVICE IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
2. THIS DEVICE MUST ACCEPT ANY HARMFUL INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

This device generates and uses radio frequency energy and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC which are designed to provide reasonable protection against such interference.

#### FCC Warning:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such change or modifications could void the User's authority to operate the equipment.

#### Battery Safety Information

Batteries may leak fluids that can cause damage to your toy. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the toy.
- Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging.
- If rechargeable batteries are used, they should be charged according to manufacturer's specifications and under adult supervision.

#### Battery Performance Note

For best performance, use alkaline batteries. Battery life will vary according to brand.