



The **REVOLUTION**

Advanced Wireless Adjustable Bed
with Bluetooth Sound System
& Power Lumbar Adjustability

Wireless Hand Remote Operation



E. LED Signal Light

A. Raises the Head of the Bed

B. Lowers the Head of the Bed

P. Increases Lumbar Support


F. Returns Head & Foot to **FLAT** Position (hold 3 seconds)

H. Increases the Intensity of Vibration (Head)

I. Decreases the Intensity of Vibration (Head)

M. Full Body Massage

N. Turns on Massage Wave 1, 2 or 3



C. Raises the Foot of the Bed

D. Lowers the Foot of the Bed

G. Pre-Programmed Memory Positions

Q. Decreases Lumbar Support

J. Increases the Intensity of Vibration (Foot)

K. Decreases the Intensity of Vibration (Foot)

L. Stops Massage

O. Under Bed Light



Head and Foot Position Adjustments (A, B, C, D)

• Use to raise or lower the head and foot sections of your adjustable bed. The premium "Wall-Glide" feature will automatically synchronize with all Head & Foot adjustments.

LED Signal Light (E)

• Indicates signal is being sent for operating function.

Bed "Flat" Button (F)

• Press down and hold for 3 seconds to return bed to the flat position.

Pre-Programmed Memory Position (G)

• These 3 program function keys allow you to select the most popular positions with one touch.

Head and Foot Massage Adjustments (H, I, J, K)

• Use to activate the massage feature on the head and foot of the bed (starting at intensity 4 of 8). Gradually increase or decrease intensity of massage vibration by pressing the appropriate button. The lowest setting on each massage unit will turn off the respective vibration. The massage feature is programmed with an Auto Shut-Off Timer that will automatically turn off the massage after 15 minutes of continuous use. A 5 minute cool down is required before initiating an additional massage sequence.



**Contouring
"Head Tilt"
Feature now with
Power "Lumbar"
Adjustability**

FOR YOUR SAFETY, READ THE OWNER'S MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS PRODUCT. ELECTRIC SHOCK MAY OCCUR IF ELECTRICAL COMPONENTS ARE NOT INSTALLED OR OPERATED ACCORDING TO THESE GUIDELINES.



The **REVOLUTION**

Advanced Wireless Adjustable Bed with
Bluetooth Sound System & Power Lumbar Adjustability

Wireless Hand Remote Operation

Continued



Stop Button (L)

- Hold down for 2 seconds to stop massage.

Full Body Massage (M)

- Press to activate both the head and foot massages at the same time.

Wave Massage Adjustments (N)

- Activates both units to wave mode massage. **NOTE:** You must stop the massage in order to activate another massage setting such as full body or another wave massage.

REMEMBER: YOU MUST STOP MASSAGE BEFORE ALTERNATING BETWEEN MASSAGE FUNCTIONS.

Under Bed Light (O)

- Press the button to turn on or off the under bed light. (Button on back of Hand Wand)

Lumbar Adjustments (P,Q)

- Activates the power Lumbar System which gently increases or decreases lower back support

REMOTE FEATURES

- The Adjustable Bed uses a RF (Radio Frequency) hand control system.

NOTE: This bed may show minor intermittent performance because of typical RF interference. This is normal in the operation of the bed, not a defect.

- The buttons are backlit, when pressed, to aid in the visibility of the remote in low light environments.
- It is not necessary to face the receiver to operate the remote control. Remote signal is best transmitted within 9 feet (3 meters) of the receiver.

SAFETY

- In the case that an overload of weight is placed on the head or foot mechanism, the control unit will automatically stop all functions. The control unit will automatically resume all functions 30 seconds after excess weight is removed.
- Massage motors will automatically shut off after running continuously for 15 minutes. All massage functions will be operational again after 5 minutes.
- The input transformer voltage is AC120V 60HZ, the output voltage is DC24V 3A. In the case of a short-circuit, a fuse on the transformer will blow to protect the electrical equipment (Fuse: 1A~1.5A.). Should this occur, you **MUST** seek professional assistance to replace the fuse. **Call Customer Care at: 1-877-826-8757**

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Important Note: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.