



3. Install 1x AA battery into the Mouse, install 1x AA batteries






1. The LED indicator on the mouse and keyboard will flash for a few seconds, and indicate that the products are now worki

3 level DPI 1000/1600/2400, press the DPI key, available to switch between the three gears till you like. During the switching process, twice for 1000DPI, twice times for 1600DPI, three times for 2400DPI.



2. Polling rate regulation

Click the middle button and the right button at the same time for 3s and the polling rate will change between 125Hz and 250Hz.
When it comes to 125Hz, the LED will slowly flash three times: when it comes to 250Hz. the LED will quickly flash three times.



The LED indicator on keyboard and the mouse will be flash in RED when the battery



Manual

is going to out of work, please replace new battery in time.

4. Automatic sleep

If you do not use the mouse after stopping, the mouse will enter hibernation state. You can wake it up by pressing the button or moving the mouse (press the button to wake it up after stopping for about 15 minutes)

5 Keyboard :FN key function Press FN + F1~F12 for multi-media

6. Reprogramming the devices


Keyboard and Mouse and receiver need to reconnect under the condition of High temperature, high magnetic, strong vibrate Power outages. Mouse connection:


1. Plug the Nano receiver into the USB

ouse within 30CM to Nano receiver reinstall the battery, Press the left, center and right keys at the same

3. Your mouse should now be synced.

Keyboard connection: 1. Plug the Nano receiver into the USB





用按键或移动鼠标即可唤醒(放停约15分钟后需

5. 键盘: FN键功能

对码成功,便可使用无线键盘了。

按FN + F1~F12进行多媒体功能。

Manual

his mouse uses 2.4GHz radio waves to transmit data with a working distance of 10m. Ensure that there are no large objects

Tip: Remove the battery if the mouse is not going to be used for long periods of

This equipment complies with Class B rules in digital apparatus and complies with Part 15 of the FCC Rules.

The warranty period of our products is 12 months from purchase If a defective is found due to qualified problems of the product, Service Email: Eyoososervice@163.com

Package content Wireless Mouse Nano Receiver

Wireless Keyboard User Manual

Eastern Times Technology Co.,Ltd. Add: Building D,Nan An Industrial Area,Youganpu Village, Fenggang Town,

| Dongguan City,Guangdong,China | TEL:86-769-86800666 | Service Phone Number:400-865-9898 | Fax:86-769-86800338 | Welcome to Address: www.eyspc.cn

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model. DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact.

with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity

outside of the product itself), or other non-standard operating

condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful

Failing to follow all safety guidelines may result product damage. explosion, fire, and/or electric shock

FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installations are supported to the provide reasonable protection provides the provided to the provide installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:— Reorient or relocate the receiving

- Increase the separation between the equipment and receiver
- Increase the separation between the equipment and received:
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation



E-Y0050®



Quick Start Guide

Model: E-787 2.4GHz Wireless Keyboard and Mouse Combo

说明书

产品特色

- 2.4G工作频率,通用性强,无遮挡传输距离远达10米。 ●使用红外线作为移动寻迹光源,耗电量低,过面能力强。
- 分辨率3档可调 1000/1600/2400DPI。 人体工程学原理的外形设计理念。
- 系统支持 WINXP/Vista/WIN7/WIN8/WIN10/WIN11。
- 微型(Nano)接收器,即插即用。

产品安装

1.从包装盒里取出无线键盘,鼠标及接收器。



Nano 接收器

无线键盘



2.把超微型(Nano)接收器插入主机的USB接口。





说明书

3.把1节AA碱性干电池按正确极性装入键盘内部,把1节AA碱性干



装入键盘由池

产品高级功能

轮下的红色 LED 指示灯: 1000DPI 闪烁 1 次, 1600DPI 闪烁 2 次, 2400DPI 闪烁 3 次。



将在125Hz和250Hz间切换,当切换到125Hz时,鼠标滚轮下红色LED将慢闪3次,当切换到 250Hz时,鼠标滚轮下红色LED将快闪3次。

3. 电池低电压提醒功能

请及时更换新的电池。





说明书

4.自动休眠 放停后不使用鼠标,鼠标将进入休眠状态,使







1. DPI 调节功能 鼠标具有 1000/1600/2400 三档 DPI 调节。如 果您想切换其他的速度, 请按 DPI 键切换按钮 即可以在这三档之间切换,切换过程中,鼠标滚



同时按住鼠标的中键和右键约3秒,鼠标回报率

键盘和鼠标上的LED指示灯出现红色闪烁时,


装入鼠标由池

键局在高温 高磁场 振动 断由的情 况下识别码将消失,需要重新连接才可 以使用, 方法如下:

1 将Nano接收器插入USB端口。 . 将鼠标离接收器30CM重新装入电池。

同时按下左中右三键,即可连接成功。 3. 对码成功,便可使用无线鼠标了。 无线键盘连接·

6. 重新连接







● 注意事项 本产品使用2.4GHz无线电波传送数据,无遮挡使用距离为10米内, 确保鼠标和Nano接收器之间有较大的障碍物,环境干扰,使用距离 将减少,在凹凸不平,反光等桌面上可能影响鼠标的使用。

说明书

提示: 如果键鼠标长时间不使用,请取出 电池, 以免腐蚀机件。



4

此设备必须符合FCC 第15条的规定。

我们的产品保修期为12个月。如因产品存在质量问题而发现缺陷, 请与我们联系; 电子邮件服务: Evoososervice@163.com

包装内容

无线鼠标 无线键盘 USB接收器

东莞市丰润计算机有限公司

地址: 广东省东莞市凤岗镇油甘埔村南岸 工业区D栋 传真: 86-769-86800338

⚠ 注意

如果电池更换不当会有爆炸危险 只能用同样类型或等效类型的电池来更换

- --用错误型号的电池组替换,可能会使安全防护失效(例如,对某
- 世类型的钾电池组): --将电池组投入火中或加热炉中,或对电池组进行机械挤压或切 割的处理可能导致爆炸;
 --将电池组放置在极高温度环境中,可能导致爆炸或泄漏可燃液
- 体或气体;和 --电池组承受极低气压,可能导致爆炸或泄漏可燃液体或气体; --非专业人员请勿拆解或维修此产品,否则有可能造成产品进一 步的损坏或人身伤害!

外壳及附件

品中有害物质,按部件分类,声明如下。

P刷电路板组件 X O O O

本表格依据SJ/T 11364的规定编制。 O:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572

为满足中国电子电气产品有害物质限制相关的法律和其它要求,对本产

有害物质

铅 汞 镉 六价铬 多溴联苯 多溴二苯醚

0


0

0

0

✓ 表示该有事物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 表中标记" X "的部件,皆因全球技术发展水平限制而无法实现有害

们剧由路板组件·包括印刷由路板及其零部件。由子元器件等 根据产品型号不同,您所购买的产品可能不会含有以上所有部件



《废弃电器电子产品回收处理管理条例》

F元素倡导环保和低碳的消费体验。建议拥有该产品的用户在不需 要此产品时,应遵守国家废弃电器电子产品回收处理相关法律法规,将 其交给当地具有国家认可的回收处理资质的厂商进行回收处理,降低资 源浪费,保护地球自然环境。

元素



快速入门指南 型号: E-787 2.4GHz无线键鼠套装

型号	E-787-8804+2750				75*W105mm				
名称	说明书		材质:80g书写纸						ilk *₩
日期	2023-2-8 1 OF 5		印刷: 单黑双面印刷](0)	
页码			文件编号						
绘图	何周平	审核			核准			版本	A.0