

Senao IAP2300M

AX3000 Indoor Ceiling/Wall Mount AP

QSG

Hardware Overview

Ports




Mounting Method

The access point can be mounted on the Ceiling and Wall. Please perform the following steps to install the device.

Ceiling Mount

1. Screw the clips onto the bottom of the device.



2. Hook the clips onto T-Rail until you hear a click.



Wall Mount

1. Determine where the **Access Point** will be placed and mark the location on the surface for two mounting holes. Use appropriate drill bit to drill two 8.1mm diameter and 26mm-deep holes on the marks.
2. Screw the **Anchors** into the holes until they are flush with the wall; screw the **Screws** into the **Anchors** but leave the screw head sticking out so you can hang the **Access Point** on it.



3. Hang the **Access Point** against the wall onto the **Screw** heads.




(Anchors size: Φ 8.00mm x L 25mm / Screws size: Φ 5.00mm x L 16mm)

Powering the AP

Connecting to a PoE Switch


Connect the Ethernet cable from the EnGenius Fit AP directly to the PoE port of the PoE switch.



Powering with a PoE Adapter


(A) Connect one end of the Ethernet cable into the LAN (PoE) port of EnGenius FIT AP and the other end to the PoE port on the PoE Adapter.

(B) Connect the power cord with the PoE Adapter and plug the other end into an electrical outlet. (C) Connect the second Ethernet cable into the LAN port of the PoE Adapter and the other end to the Ethernet port on the computer.



Powering with a Power Adapter

Connect the Power Cord to the adapter, and then plug the Power Cord into the power outlet.



Statement

Senao Networks, Inc.

AX3000 Indoor Ceiling/Wall Mount AP

FCC ID: U2M-IAP2300M

1. USA—Federal Communications Commission (FCC)

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the equipment and the receiver.
- Connect the equipment to outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US.

Operation of this device is restricted to indoor usage only.