

User Manual

Model Name: F035A, FCC ID: U53-F035A

Introduction for installation

- 1) Open the back cover of the transmitter and insert one piece of A23-12v battery. Close the back cover and mount the transmitter on your door.
- 2) Connect the receiver to AC power indoor.

Function Introduction

- 1) This product can be used both as night light and doorbell
- 2) For wireless doorbell use, when your guest presses the button of transmitter outdoor, the receiver indoor will be activated and makes melodies. The “🎵” button can offer you options of 24 pieces of music
- 3) For night light use, when turn to “💡” , the light will work

when turn to “🌙💡” , it goes into light control mode, it will automatically work in daytime and stop at night.

when turn to “🔌💡” , it will be activated by the transmitter outdoor and the night light will work and flash with doorbell music together.

NOTE:

1. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.
2. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
3. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.