

Contents

Thank you.....	22
Overview.....	23
Choosing wearing preference.....	23
Disassemble the plaque.....	25
Glossary.....	26
Specification(BT8028).....	26
Pairing.....	27
Using your BT8028 headset.....	28
1. To answer a call direct from your mobile phone.....	28
2. To answer a call direct from your headset.....	28
3. Call reject.....	28
4. To make a call.....	28
5. Voice-dialing(if supported by phone).....	28
6. To end a call.....	28
7. To make a re-dial.....	29
8. To adjust the volume.....	29
9. To turn the headset on and off.....	29
10. Charging.....	29
Storage.....	29
Troubleshooting and frequently asked questions.....	30

Design and specifications are subject to change without notice

Thank you

Thank you for purchasing the BT8028 bluetooth headset, we hope you will be totally delighted with its operation. The BT8028 is a simple and easy way to enjoy handsfree use of your Bluetooth mobile phone. The BT8028 is designed to be comfortable enough to be worn all day.

Please read the instruction manual to get started.

Drive safely




Using a mobile phone while driving creates a distraction to the driver which may increase the likelihood of an accident.

When using the phone while driving, keep conversations short and do not make notes or read documents. Before answering calls consider your circumstances. Pull off the road and park before making or answering calls when driving conditions require (e.g. bad weather, high traffic density, presence of children in the car, difficult junction or manoeuvres.)

Abide by local laws!

Overview



- 1 Charging port
- 2 Ear hook
- 3 Function button
- 4 Volume button
- 5 MIC
- 6 Indicator light

Choosing wearing preference

For comfortable, please:




Don't hold the body but ear hook to wear the BT8028 on your ear.





BT8028 is ready to wear on the right ear. If you prefer the left, gently rotate the ear hook.

180° rotate



In general, you will get better performance when there are no obstructions between the headset and the mobile phone. For optimal performance, wear the BT8028 and your mobile phone on the same side of your body or within line of sight.

Disassemble the plaque



Glossary

- 1. Bluetooth** is a radio technology developed to connect devices, such as mobile phones and headsets, without wires or cords over a short distance of up to 10 metres (approx 30 feet). More information is available at www.bluetooth.com
- 2. Bluetooth profiles** are protocols through which Bluetooth devices communicate with other devices. Your phone needs to support either the handsfree or headset profile to function with the shinwa BT8028.
- 3. Pairing** creates a unique and encrypted communication link between two Bluetooth enabled device and allows them to communicate with each other. Bluetooth devices will not work if the devices have not been paired with each other.
- 4. Passkey or PIN** is a code that needs to be entered on the phone in order to pair the mobile phone with the BT8028. When you have already paired your mobile phone with the headset, the phone and the BT8028 will recognize each other automatically accept the transmission.

Specification (BT8028)

Bluetooth Specification: V1.2
 Talking time: 4~5 h
 Stand-by time: 120 h
 Distances: 10 m
 Weight: 18 g
 Battery: 130 mAh
 Size(main unit): 65x35x25 mm

Pairing



NOTE: It is only the first time you want to connect your BT8028 with your phone that you need to pair the two devices.

Set your Bluetooth phone to "discover" the BT 8028

Follow your phone's instruction guide. This usually involves going to a "setup", "connect", or "Bluetooth" menu on your phone and then selecting the option to "discover" a Bluetooth device.
(See example from a Sony Ericsson T610)



Your phone will find the "BT 8000"

The phone then asks if you want to pair with it. Confirm by pressing "yes" or "ok".

Enter passkey or PIN: 0000(4 zeros), then press "yes" or "ok"

If pairing was successful

The blue light(LED) will briefly flash rapidly.

Using the headset

After connecting, you're ready to use your BT8028 headset.

1. To answer a call direct from your mobile phone

Press the answer button on your phone's keypad. You can subsequently transfer the call to your headset by a tap on the headset's answer/end button.

2. To answer a call direct from your headset

Tap once on the headset's answer/end button.

If you choose to take the call directly from the headset, the time for the call to transfer from the mobile phone to the headset will depend on the phone model. To avoid missing calls, we recommend that you answer calls on your mobile phone and then transfer the call as described above.

3. Call reject

To reject an incoming call, Press and hold the function button around 2 seconds.

4. To make a call

Use your mobile phone's keypad to dial the number, then the call will transfer to your BT8028.

5. Voice-dialing(if supported by your phone)

First, ensure voice dialing function of your phone is turned on. Then press on the function button, when you will hear a short tone, and make voice dial by saying a voice tag .(for further information about using this feature, please consult your phone's user manual)

6. To end a call

Tap the end button on your mobile phone or the function button on your headset.

7. To make a re-dial

Roll downwards the volume button, till you hear a short tone, then the last number you've dialed with redial automatically.

8. To adjust the volume

To increase the volume, roll upwards the volume button.
To decrease the volume, roll downwards the volume button.

9. To turn the headset on and off

To turn the headset on

Press the function button for 3 seconds around until the indicator light flashes blue continuously.

To turn the headset off

Press the function button for 3 seconds around until the indicator light flashes red continuously and then switches off.

10. Charging

Whenever the charger plugs in the headset, the indicator light will turn red. When the charging is completed, the red indicator light will shut off.

Storage

1. Store the headset with power off and safely protected
2. Avoid storage at high temperatures (above 45°C/113°F), which will reduce battery life and degrade performance. Low temperature (down to -10°C/14°F) will shorten battery life and may affect operation but should not permanently damage the BT8028.
3. Don't expose the headset to rain or other liquids.

Troubleshooting and frequently asked questions**If you can hear crackling noises:**

For the best audio quality, always wear your headset on the same side of the body as your mobile phone.

If you cannot hear anything in your headset:

1. Increase the volume on the headset.
2. Ensure that the headset id paired with the phone.
3. Make sure that the phone is connecting to the headset-if it dose not connect either from the phone's Bluetooth menu or by tapping the answer / end button, carry out the pairing procedure.

Will the BT8028 work with other Bluetooth equipment?

The BT8028 is designed to work with Bluetooth mobile phones. It can also work with other Bluetooth devices that are compliant with version 1.1 or 1.2 and support headset and/or hands free profile.

Will my BT8028 interfere with my car's electronics, radio, or computer?

The BT8028 produces significantly less power than a typical mobile phone. It also only emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.

I am experiencing pairing problems though my phone is indicating otherwise:

If you have deleted your headset pairing connection in your mobile phone, the only way to successfully pair the BT8028 with your mobile phone is to follow the pairing instructions.

Federal Communications Commission (FCC) Statement**15.21**

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.