


GD67CT Portable Speaker



Quick Start Guide

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The symbol means that the unit complies with European safety and electrical interference directives.

Disclaimer

Updates to hardware components are made regularly. Therefore some of the instruction, specifications and pictures in this documentation may differ slightly from your particular situation. All item described in this guide for illustration purposes only and may not apply to particular situation. No legal right or entitlements may be obtained from the description made in this manual.

Safety precautions

- Never subject speaker to extremes of light, temperature, moisture or vibration.
- Do not use or store speaker in a location subject:
 - A. Extreme high temperature, such as in a sun-heated car

GD67CT Quick Start Guide


B. Direct sunlight

C. High humidity or places with corrosive substances


D. Sub-zero condition, especially during winter.

- Clean only with a dry cloth.
- Don't block any of the ventilation openings, install according to the manufacturer's instructions.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way.


Parts and Control



Power/ Bluetooth button



USB port



Line-in cable

Power/Bluetooth button – slide to turn the speaker on/off or for setting Bluetooth mode.

USB port – for emergency charging.

Line-in cable – for connecting to music source device.

Accessories

1 X GD67CT portable speaker


1 X USB cable

1 X Quick start guide

Getting Started

1. Remove speaker from packaging.

2. Press down on the base of the speaker to release the extension base.



3. Then base “pops up”, press the base down


again to collapse the base.

Charging the GD67CT speaker

Connect the speaker to the PC via the provided USB cable. Before using the product, charge it for 2 hours, till the LED turn from Red to off. The speaker can play up to 3hours after fully charged.

Turning On/Off the GD67CT speaker


To turn on the GD67CT portable speaker, slide the **Power/Bluetooth** button at the middle of the bar, then the blue LED will light up.



To turn off the GD67CT portable speaker, slide the **Power/Bluetooth** button to the left "**Off**" side of the bar.

Playing the music

1. Unwind the Line-in cable around the portable speaker base.




2. Plug the Line-in cable to the music source, e.g. PCs/laptops, MP3 players or radios.
3. Turn on the unit.
4. Start playing the selected music or radio from the music source.

Setting Bluetooth mode

GD67CT Quick Start Guide

1. Upon powering on, continuously slide the **Power/Bluetooth** button to be towards the “**CT**” side to set bluetooth mode.



2. Search for Bluetooth name for GD67CT Speaker in your Bluetooth device.
3. Select the Bluetooth name for GD67CT speaker for pairing (No pairing password is required.).

Technical Specifications

Audio

Output Channel: Mono

Output Power (Max): 3.0W

Frequency response: 80Hz ~ 20KHz

Sensitivity: 90dB

Sound pressure level: 65dB

Signal to noise ratio @ 1KHz Input: 80Db

Bluetooth

Bluetooth Profile: A2DP, AVRCP

Bluetooth Version: V3.0+EDR

Frequency : 2.4GHz

Working Distance:Up to 10M (Line of Sight)

Antenna Type: Internal antenna

Connectivity

Audio: 3.5 mm audio cable

Power: Mini USB

Power

Battery Type: Built-in Li-ion polymer 250mAh

Battery Cycle Life: 300 cycles

Playback Time:Up to 3 hrs (approx.)

Charging Power: 5V, 500mA (max)

Charging Time: 1 hrs: 80%, 2 hrs: 100%

Environmental Condition

Storage Temperature: - 20°C+40°C/ ± 5°C

Storage Relative humidity: 60 ± 15 %

Operation Temperature: - 20°C+40°C/ ± 5°C

Operation Relative humidity: 60 ± 15 %

Certification

CE, FCC, ROHS Packaging Material Directive

Physical Properties

Dimension: 70 x 70 x 37 mm

Weight: 91.5g

Recycling



This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE).

This means that this product must be handled pursuant to European Directive 2002/96/EC in order to be recycled or dismantled to minimize its impact on the environment.

For further information, please contact your local or regional authorities.

Electronic products not included in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances.