



2.4GHz Digital Cordless Laser Mouse with nano receiver

With 2.4GHz technology for improved range and less interference in cordless operations



RF-7600L

2.4GHz Digital Cordless Laser Mouse with nano receiver

CONTENTS

English Quick Installation Guide.....	1-1
Deutsch Bedienungsanleitung.....	2-1
Francais Manuel d'utilisation.....	3-1
Spain Manual del usuario.....	4-1

2.4GHz Digital Cordless Laser Mouse with nano receiver **US 1-1**

2.4GHz Digital Cordless Laser Mouse with nano receiver

Welcome

Congratulations on your purchase of an i-rocks™ cordless laser mouse. The i-rocks™ Digital Cordless notebook mouse uses the latest Frequency Hopping Spread Spectrum (FHSS) 2.4GHz ISM RF technology to provides the most powerful and reliable cordless user experience available. Unlike conventional 27 MHz wireless mice, with their shorter, less reliable operating range and their susceptibility to interference, 2.4 GHz ISM technology enables a consistent 10M range also provided 8 Millions ID for device to free devices conflict problems with virtually interference-free operation, and plug-and-play performance.

This notebook mini mouse provides instant access to two easily selectable sensitivity levels 1,600 and 800dpi resolution - for precise, accurate, and fast response. The scroll wheel allows you to scroll and zoom easily. The cordless mouse will be the perfect addition to your notebook PC by providing excellent accuracy, wireless freedom, and distinctive styling.

This installation guide describes how to connect the mouse receiver to your computer and set up the radio link for RF mouse.

Package Contents

- Cordless Laser mouse X 1
- USB Nano receiver X 1
(Stored in mouse body)
- AA size alkaline batteries X 1
- Travel pouch X 1(Optional)
- Quick installation guide X 1




2.4GHz Digital Cordless Laser Mouse with nano receiver **US 1-2**


Hardware Installation

Set up the mouse


- Open the battery housing cover under the cordless mouse's bottom side.



- Install the provided batteries into the battery housing.
(Please follow the polarity signs in the battery housing.)




- Close the mouse battery housing cover.
- Switch the button to " H " for 1600 dpi resolution , to " L " for 800 dpi resolution and to " OFF" for power off.




- Please turn off the power for saving power if you don't use the mouse at the long time.
- Ready to use.

2.4GHz Digital Cordless Laser Mouse with nano receiver **US 1-3**

Note1 : Some products own the side buttons, the button function define as below.
The Backward & forward button are only for fast control of Internet browser.



Note2 : Battery low indication. when the battery light is flashing , please turn off the power then change the new battery.




ID Setting

In general, the mouse was done the ID setting while product, User doesn't do any thing about the ID setting. But in case of ID missing, please refer the below description for ID setting.

Each cordless mouse has to get an ID from a specific receiver before start working, it also called ID Setting. The ID-Setting helps to protect against interference from other cordless mouse in the same environment. Please follow below steps to complete the necessary ID-Setting process for your cordless mouse and USB dongle receiver.

2.4GHz Digital Cordless Laser Mouse with nano receiver **US 1-4**

1. Make sure the mouse hardware installation is completed.
2. Plug the USB receiver into your computer's USB port.



3. Waiting for the USB plug and play initialization completed, and the receiver LED will light flush.
4. Move your cordless mouse and close to the USB receiver within 30cm, press and hold the mouse left button and right button then turn on the power button on the bottom of mouse at the same time. It will take about for 3 to 4 seconds to set ID connection.
5. Once the ID setting process is completed, the receiver LED will light off. The receiver LED will light on again when cordless mouse is working.
6. If the mouse doesn't work properly, please remove the USB receiver from computer's USB port, then repeat do step 3 to step 4 again.

Troubleshooting

What do I do if the cordless mouse does not work?

- Check the USB receiver is connected to your computer's USB port.
- Make sure the batteries are correctly installed into your cordless mouse.
(The positive (+) and negative (-) ends of each battery must match the polarity signs in the battery housing)
- Make sure the batteries power qualities are good for use.
- Make sure the ID-Paring process is well completed.
- Please change batteries immediately when the cordless mouse battery low LED glow red or the cursor on screen does not move or move erratically.
- **Warning** : Please remove batteries from your cordless mouse when not using for a long period of time.

System Requirements

To use the cordless mouse, your computer must meet the following hardware requirements and run one of the operation system listed below.

- One USB port
- Microsoft® Windows® 98SE, ME, 2000, XP, Vista™, Windows® 7™ or above
- Macintosh® OS X 10.1 or later
(Don't support the side buttons function on the MAC OS.)

All product names are trademarks or registered trademarks of their respective owners.
Microsoft®, Windows® and Windows® logo are trademarks or registered trademarks of Microsoft® Corporation in the United States and /or other countries.

2.4GHz Digital Cordless Laser Mouse with nano receiver

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Ⓞ Reorient or relocate the receiving antenna.
- Ⓞ Increase the separation between the equipment and receiver.
- Ⓞ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Ⓞ Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example – use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



I-ROCKS TECHNOLOGY CO., LTD.

Headquarter Office

12F, No. 190, Chung-hsin Rd., Sec. 2,
Hsin-tien City, Taipei, 23146 Taiwan, R.O.C.

Tel : +886-2-2911-3080

Fax : +886-2-2914-1712

Website: www.i-rocks.com

China Factory

Zhen Hua Road, Tie Lu Keng Village, Qi Shi Town,
Dong Gang City, Guang Dong Province. China

- Specifications and pictures are subject to change without notice.
- All brand names and products are registered trademarks of their respective companies.