

M23R 2.4GHz Cordless Silent Mouse

Model No.: IRM23R

Quick Installation Guide




2.4GHz Cordless Silent Mouse

Package Contents

- Cordless mouse X1
- · Nano dongle X 1

- · Battery AA X1
- · User's Manual X1



System Requirements

- Microsoft Windows system: Windows® 7, Windows® 8.1, Windows® 10
- · Available USB Port

Features

Mouse

· Interface : Cordless 2.4GHz

· Buttons: 5 buttons (Left / Right buttons for silent button)

· Resolution: 600/1000/1600/2400 dpi Optical

· Power On/Off switch

· Effective Distance: Approx. 10 M

· Battery power life: Approx. 12 months (4 hrs a day, 5 day a week)

· Batteries : AA x 1

2.4GHz Cordless Silent Mouse



Dimension: 106 (L) X 57 (W) X 33.5 (H) mm
Weight (battery excluded): Approx. 60 g

Receiver

Interface · USB

· Dimension : 20 (L) x 12 (W) x 5 (H) mm

Hardware Installation


 Set up the Mouse (Put provided batteries into mouse's batteries housing)

- · Open the battery housing cover as picture.
- Install the provided batteries into the battery housing.
 (Please follow the polarity signs in the battery housing)
- · Close the mouse battery housing cover.
- Turn on the power switch on the back of mouse.



- 2. Easy automatic cordless connection:
- Connect the USB nano receiver to your computer into your PC USB port, wait until automatic installation has completed.
- 3. Ready to use.

Product Function



600 dpi 1000 dpi (Default) 1600 dpi 2400 dpi

Troubleshooting

What do I do if the cordless mouse does not work?

- Check the USB dongle receiver is connected to your computer's USB port.
- Make sure the batteries are correctly installed into your cordless mouse and keyboard.
 - (The positive (+) and negative (-) ends of each battery must match the polarity signs in the battery housing)
- · Make sure the batteries power qualities are good for use.
- · Make sure the ID Setting process is well completed.
- Please change batteries immediately when mouse works on screen does not move or move erratically.
- Please change batteries immediately when the cordless mouse battery low indicator light up.
- Warning: Please remove batteries from your cordless mouse when not using for a long period of time.
- Mouse will have reduced tracking performance on very shiny or transparent surfaces.
- Cordless performance: Metal object close to or in between the device. (Please remove objects.)

Cordless ID Setting

The cordless mouse were already pairing OK before shipment. So the user does not need to do any pairing. Once need to re-pairing, please follow below steps to complete the necessary ID-Setting process for your cordless mouse and USB dongle receiver.

- 1. Make sure the mouse hardware installation is completed.
- Unplug and Plug again the USB dongle receiver into your computer's USB port.
- 3. Waiting for the USB plug and play initialization completed.
- 4. For mouse ID setting:

Turn your cordless mouse on and move the mouse close to the USB dongle receiver within 15cm, then click and hold left and right button of mouse, then power on the switch to start ID setting process. (It will take about 4~8 seconds waiting time)

- 5. Ready to use
- 6. If the mouse doesn't work properly, please remove the USB dongle receiver from computer's USB port, then repeat do step 2 to 4 step again.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pur-suant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated ra-dio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is en-couraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Olncrease the separation between the equipment and receiver.
- ©Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ©Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example – use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two condi-tions:

(1) This device may not cause harmful interference, and(2) this device must accept any inter-ference received, including interference that may cause undesired operation.



i-Rocks Technology Co., Ltd. Headquarter Office

7F., No. 786, Zhongzheng Rd., Zhonghe Dist.,

New Taipei City 23586, Taiwan

Tel: +886-2-2225-5080 Fax: +886-2-2228-1712

www.i-rocks.com

i-Rocks Korea

www.i-rocks.co.kr

i-Rocks Malaysia

57-A, Jalan SS21/1A, Damansara Utama, 47400,

Petaling Jaya, Selangor, Malaysia

Tel: +603-77339233 www.i-rocks.com

IRM23R