


1.02 Screen transitions in speed lock mode








- *1 The screen gets locked as long as the current speed reached 6km/h
- *2 The lock will be released when the current speed reduced to 2km/h.
- *3 The targets of speedlock are BT automatic pairing and HDMI.
- *4 As an example the above screen transition shows how speedlock effects when playing a video.

1.03 Screen transitions to test screen, Clear screen, RearCamera view screen, Incoming call screen and Screen OFF



*If the screen was OFF when received the call, the screen will turn off again if no other operation for 5 seconds after the call ended.

1.04 Screen transitions of playing AM radio



press [Left Arrow] to step up
Long press [Left Arrow] to seekup

Long press >> to seekdown
(if there's searched available channel)

Long press << to seekup
(if there's searched available channel)

press >> to step down
(No available channel)

press << to step up
(No available channel)

press >> to step down
Long press >> to SeekDown

Press [A SEL] to search available channels
[Cancel]

press [SCAN] to scanning available channels
Scan ended
Press any key (except Mute and Volume) or tap the screen to stop scanning

Search ended

Search ended.No available channel

The telop disappears if no other operations for 5s
If it was playing a channel in Preset List, go back to that channel after the search ended

The telop disappears if no other operations for 5s
If it was playing a channel in Auto List, set to the 1st channel in Preset List after the search ended

The telop disappears if no other operations for 5s

[Auto]
Tap a channel in the list to play it.


go back to the previous channel

go back to the previous channel


The chosen item changes to 531

[Presets]
Tap a channel in the list to play it.

1.08 Screen transitions of playing FM radio




1.06 Screen transitions of playing USB Audio




- *1 Tap the process bar to move back and forth to another stage
- *2 When playing an audio source, press [] to pause it and press [] to resume it
- *3 Press [] or [] to switch to the next/previous track
- *4 Long press [] or [] to fastforward/fastrewind




1.07 Screen transitions of native BT Audio



1.08 Screen transitions of native BT Phone



1.19 Screen transitions of vnaix iPod



1.1.1 Screen Transitions of Settings



This device complies with part 15 of FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines.

This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation (MPE).