


Technology at Work.®



JANAM
XT40 Series™
 Quick Start Guide

Battery Warning

CAUTION

**IF MISUSED OR MISTREATED THE BATTERY MAY PRESENT A RISK OF FIRE OR CHEMICAL BURN.
 RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
 DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.**

BATTERY SAFETY GUIDELINES.

Use only Janam XT40 Series batteries and recharge batteries using only Janam approved charging accessories. Observe the following guidelines for safe use of Li-Ion batteries:

1. Do not expose the battery to excessive heat or cold. Do not short-circuit. Do not incinerate.
2. To avoid risk of fire, burn or damage to your battery, do not allow a metal object to touch battery contacts.
3. Do not disassemble the battery. There are no user serviceable parts inside.
4. If battery leakage is observed, avoid any contact with affected area and properly dispose of the battery.
5. If you come in contact with battery leakage, rinse exposed area with soap and water. If it contacts the eye, flush the eye with water for 15 minutes and seek medical attention.
6. Dispose of used battery promptly. Keep away from children. Do not disassemble or dispose of in fire.
7. When discarding a battery, contact your local waste disposal provider to understand local restrictions for disposal or recycling of batteries.

BATTERY CHARGER SAFETY GUIDELINES.

1. Do not use the equipment in or near areas in which sparks are likely or possible.
2. Do not let equipment's metal contacts and electrical sockets come in contact with metal objects.
3. For indoor use only. Do not expose the equipment to rain or any liquids.
4. Do not use or store the equipment in direct sunlight or in areas that are prone to get hot such as in a parked vehicle, near a heat duct or close to other heat sources.
5. Keep equipment's metal contacts and electrical sockets free from debris that could obstruct charging or could cause a short circuit.

XT40 Series Quick Start Guide

Copyright 2019 Janam Technologies LLC. All rights reserved.

XT40 Series, Janam and the Janam logo are trademarks of Janam Technologies LLC. Other product and brand names may be trademarks or registered trademarks of their respective owners.

Janam Technologies LLC assumes no responsibility for any damage or loss resulting from the use of this guide. Janam Technologies LLC assumes no responsibility for any loss or claims by third parties which may arise through the use of this product. Janam Technologies LLC assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery or repairs. To protect against data loss, be sure to make backup copies (on other media) of all important data.

Follow all usage, charging and maintenance guidelines in the Product User Guide. If you have questions, contact Janam. For a copy of the Product User Guide, visit www.janam.com.

Important: Please read the End User License Agreement for this product before using the device or the accompanying software program(s). Using the device or any part of the software indicates that you accept the terms of the End User License Agreement.

Content and Additional Resources

To help you get started with your XT40 Series mobile computer, this guide features:


- Hardware Overview
- Getting Started
 - A. Install the Battery
 - B. Charge the Battery
 - C. Remove the Battery + Access MicroSD and SIM Card Slots
- Battery warnings and safety guidelines.

Contents of this guide are subject to change. For the most current version of this guide and additional product details, visit www.janam.com.

For software updates and information, visit www.janam.com/product-zone.


Hardware Overview

1. Barcode Scanner
2. Camera
3. 3.5mm Audio Jack
4. Touch Screen
5. Right Trigger
6. Power Key
7. Micro USB
8. Pogo Pin Connector
9. Volume Key
10. Left Trigger



Hardware Overview

1. Camera
2. Speaker
3. SIM Card Slot
4. MicroSD Card Slot



Getting Started

A. INSTALLING THE BATTERY

1. To access the battery compartment, remove the handstrap by pulling down the plastic clip located on the bottom of the XT40. Move both tabs on the battery cover to the "unlock" position and pull the cover away from the device.
2. Position the battery so that the text "Insert this direction." is on the left side and snap into place.
3. Replace the battery cover by positioning the bottom prongs first and snapping cover into place.
4. Move both tabs on the battery cover to the "lock" position.

B. CHARGING THE BATTERY

Important Note: The main battery charges the backup battery in the XT40 Series device. When discharged, the backup battery requires approx. 1.5 hours to recharge.

To charge the battery using the included **AC/DC Power Adapter Kit**:

1. Connect the AC/DC adapter to XT40 Series.
2. Plug in the AC/DC adapter. Use only easily accessible wall sockets that are easily reached with the length of supplied power cable.

To charge the battery using a **Cradle Kit**:

1. Connect the power supply to the cradle.
2. Plug in the power supply. Use only easily accessible wall sockets that are easily reached with the length of supplied power cable.
3. Place the device in cradle. The LED on the device will illuminate to confirm connection.
4. The battery is fully charged in approximately 2.5 hours.
5. To charge a battery in the spare battery well, insert the battery into the well top down (connectors on the battery should face downward and to the back of the cradle) and gently press down. The LED light on the cradle will illuminate to confirm connection.

Getting Started (continued)

To charge the **Backup Battery**:

1. Navigate to the Home Screen -> App drawer -> Settings -> Battery.
2. Select "Backup Battery Charge" option.

C. ACCESSING SIM CARD SLOT and MICROSD CARD SLOT

1. Remove the back cover.
2. Remove battery from the XT40.
3. MicroSD card slots and SIM slot are now accessible. Insert the MicroSD or SIM with gold-colored contacts facing downward.
4. Replace the battery.
5. Replace the battery cover.

FCC Caution

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

IC Caution

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.

English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.