


Functions:



MP3 System
Set the vehicle's ON/OFF switch to "ON" position.
Connect and play the MP3 Player.
Control the volume with the volume controller.



Front & Rear Suspension Action.




Connect the MP3 player and press play or press the music button on the hand control, so you can listen to the music.




Spin the Spinner Rims for simulated hydraulic "UP and DOWN" function with flashing lights.

Transmitter Features



Transmitter Battery Installation


1. Locate the Battery Compartment which is on the back of the Transmitter.
2. Remove screw from battery cover by screwdriver and take down the battery compartment cover.
3. Insert 6 X 1.5V "AA" batteries (included). Make sure that the batteries are installed correctly according to the positive (+) and negative (-) marking on the battery compartment.



Note: When replacing Transmitter batteries:
Do not mix old and new batteries.
Do not mix alkaline, standard or rechargeable batteries.
Alkaline batteries recommended.
Always remove batteries from battery compartment when not in use.

Demonstration Wire Removal Ages 5+

This vehicle is shipped with a wire lead which runs from the transmitter to the vehicle chassis. The wire lead is for package demonstration only and should be removed and discarded as show here.



Proper Use and Precautions



Functions:



Forward



Backward



Forward turn left



Forward turn right



Backward turn left



Backward turn right

FCC CAUTION:
The manufacturer is not responsible for radio interference caused by unauthorized frequency modification of this equipment. Such modifications could void the user's warranty to operate the equipment.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance with the State or Federal safety regulations may void the user's warranty.

NOTE: This product is not to be used in conjunction with the Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not properly installed and used, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, you may need to take one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the transmitter and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

RC RADIO CONTROL

ROCK N' BEAT

TOYOTA TUNDRA



**LIGHT UP SPINNER RIMS
CONNECTION TO MP3 PLAYER
REMOTE ROCKING ACTION**

SCALE 1:8

Batteries Required (Included)
One 9-Volt Rechargeable Battery with Charger
Six 1.5V "AA" Batteries

TOYOTA, TUNDRA and all other associated marks, artwork and images are trademarks owned by Toyota Motor Corporation and used with permission by the manufacturer. ©2004

Vehicles Features & Charging Time



ATTENTION!
DO NOT OVERCHARGE THE 9V RECHARGEABLE BATTERY!
1. Do not charge the rechargeable battery over 4 hours with the use of a standard AC power source.
2. When you have the opportunity of the vehicle, disconnect the battery from the charging source.
3. Always stop charging and change the rechargeable battery for 4 hours enough.
4. Do not attempt to charge the 9V battery with the rechargeable battery when the battery is still operating well in the vehicle.
5. Rechargeable battery is only for single cycle use.
6. Always testing transformer when not in use.
7. Always testing the rechargeable battery from the vehicle when not in use.

Radio Control Vehicles

TROUBLE SHOOTING

90% of all difficulties experienced with radio controlled vehicles are due to either weak batteries or batteries that have been installed incorrectly. When batteries become weak, the vehicle may not necessarily stop completely but may exhibit slow response, slow speed or erratic behavior.

- Problem - Vehicle does not move or moves slowly.**
- Make sure there are fresh batteries in the transmitter and that they have been installed in the correct position.
 - Are the (+) and (-) markings on the batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
 - Has the Battery Pack been installed in the vehicle?
 - Has the rechargeable Battery Pack been fully charged?
 - Are the (+) and (-) markings on the Battery Pack in the same position as the (+) and (-) markings in the Battery Compartment?
 - Are the metal contact tabs touching, rusty or dirty in the transmitter?
 - Make certain that the vehicle ON/OFF switch is in the "ON" position.
- Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.**
- To avoid interference, ensure that no other radio-controlled vehicles on the same frequency are being used nearby.
 - Make certain that the transmitter antenna is securely attached to the transmitter.

CARE

