




## Photograph No.1 Peak output power measurement setup



Photograph No.2 Occupied bandwidth, conducted spurious emissions measurement setup


Photograph No.3 Spurious emissions measurement setup in the anechoic chamber below 30 MHz



## Photograph No.4 Spurious emissions measurement setup in the anechoic chamber in 30 -1000 MHz



Photograph No.5 Spurious emissions measurement setup in the anechoic chamber in 1-18 GHz



## Photograph No.6 Spurious emissions measurement setup at the OATS above 18 GHz





Photograph No.7 Spurious emissions measurement setup at the OATS, close view