




motorola

Product Model:SP009
Frequency Band: 2.402 -2.480 GHz
Maximum RF Power:4dBm
Working temperature: -10°C - 45°C

FCC ID:VLJ-SP009
IC :4522A-SP009




Quick Start Guide / Guia de inicio rápido / Snelstartgids / Guia de Inicio Rápido / Guida per il primo utilizzo / Schnellstartanleitung / Guide de démarrage rapide / Snabbstartsguide / Poradnik użytkownika / 快速入門指南 快速入門指南 / Краткое руководство пользователя / دليل التشغيل السريع / Hizli Başlangıç Kilavuzu / クイックスタートガイド / 빠른 시작 안내서 / คู่มือเริ่มต้นใช้งาน / Коротке керівництво користувача

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

① Pairing:




EN

- ① ▶ **play/pause /Handsfree /BT disconnect**
 - Short Press To Play /pause .
 - Press And Hold For 2s To Connect /disconnect Bluetooth
 - Double Press Can Start To " Voice Assistant "
- ② ⬆ **Volume up**
 - Short Press To Increase Volume;
 - Press And Hold For 2s To Play The Next Track.
- ③ ⬇ **Volume Down**
 - Short Press To Decrease Volume;
 - Press And Hold It For 2s To Play The Last Track.
- ④ ○ **Power on/ off**
 - Long Press And Hold Button For 3s To Turn The Speaker On/off And Selec "sonic Boost 230" From Phone Menu .
 - Short Press The Key Can Change The Mode
- ⑤ **USB Charging**
 - The Device Can Be Powered Through A Micro Usb From Any Ce Compliant Power Source That Implement The European Interface As Requested By En 301 489-52.
- ⑥ **Aux in**
 - Aux-in for connection to your electronic device
- ⑦ **Saving mode**
 - No any audio input or no function operation after 15 minutes, the main set will be automatic power off."

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

② Basic Operation:



LED Indicator	
Pairing	Blue flash
Standby	Blue flash
Charging	Red steady
Fully charged	Red off
Line in mode	Blue breathe every 5s

③ Charging:



Fully charge before use
The device can be powered through a micro USB from any CE compliant power source that implement the European interface as requested by EN 301 489-52.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L' appareil ne doit pas produire de brouillage;
- (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.