

www.**Bluedio**.com

Guangzhou Liwei Electronics Co.,Ltd



R+

HiFi

8 Track Security Precautions Overview

Security Precautions: In order to have a proper and safety use of the headset, please read this user manual in detail and save it.

## Be sure to aware the following guidelines when using your headset.

- 1. Should adjust reasonable volume and time when using the headset.
- 2. Please stop using the headset if there is any danger to ensure your safety.
- Be careful not to turn the volume so high that you can't hear anything around you. If there is a tinnitus or the volume is too high, please reduce the volume.
- Please avoid using headset to listen to music, make or receive calls to avoid distraction while driving.
- Put this product and its accessories somewhere out of the reach of children, to avoid inappropriate use by children which may cause a fatal danger.
- Should avoid water entering the headset during grooming, which may cause damage to the sound quality or the headset.
- Stop using the headset if you feel obvious discomfort, irritation or have other adverse reactions.
- 8. The headset should not be stored or use at temperatures below  $-15^{\circ}$ C  $(5^{\circ}F)$  or above  $55^{\circ}$ C  $(131^{\circ}F)$  which may shorten headset or battery life.

# Charger and battery:

Please check whether the USB charging cable is original or not before charging the Bluetooth headset.


Warning: Should use the original charging cable to charge for the Bluetooth headset, otherwise it may damage the Bluetooth headset.

# Charging:

This headset uses a non-detachable built-in Li-Polymer rechargeable battery. Do not attempt to remove the battery from the headset in order to avoid damage to the headset.

- 1. Before charging, make sure the headset is switched off.
- Plug USB cable into the charging port of headset; plug other side of USB cable into the USB charger or other charging device. Charging will start and the red light remains bright on the headset.
- The headset takes approximately 3 hours for fully charged, blue light remains bright or red light switch off after charging completed.

## Overview of R+ Bluetooth HiFi Headset:



## R+ Bluetooth HiFi Headset in the box:

- 1pc Bluetooth headset
- 1pc 3.5 mm audio cable
- 1pc USB charging cable
- 1pc Pouch
- 1pc User's Guide

### Switch On:

- Keep pressing the MF Button for around 4 seconds and the headset will issue a sound.
- Then keep pressing the MF Button for around 5 seconds. The headset will enter into pairing mode when red and blue lights blink alternatively.

## Switch Off:

 Keep pressing the MF Button for around 4 seconds until you hear the beep sound. Then the purple light blinks and the headset is turned off.

## To pair the headset with your mobile phone:

- 1. Keep distance of the headset and mobile phone (or other device needed to be connected) within 1 meter. The closer, the better.
- Switch on the headset and ensure that the headset enters into pairing mode. The red and blue lights blink alternately.
- Switch on Bluetooth search function of your mobile phone or other device needs to be connected. The mobile phone will display "R+".
- Select "R+", your headset will be automatically connected to your mobile phone, the blue light blinks.

# Hands Free Functions Technical Spec

# Last call redialing:

Double-click on the MF Button to dial out the last phone call.

### Play/Pause a track:

- 1. Press the MF Button once to pause the music.
- 2. Press the MF Button again to replay the music.

## LINE\_IN music playing and call:

- Switch on your headset by keep pressing the MF Button for around 4 seconds until the blue light blinks.
- Connect the headset with your mobile phone by 3.5mm audio cable. Then you can listen to music or make a call.
- If your headset and mobile phone are under Bluetooth connection mode, your phone will automatically change to hands-free mode when there has an incoming call.

## Music selection/ Volume adjustment:

When you are on the phone or listening to music

- Press the Previous Track or the Next Track to select songs.
- 2. Press the Vol(+) Button or the Vol(-) Button to increase or reduce the volume.

# Technical specification:

- Drive Unit: 50mm x 2pcs and 13mm x 6pcs Neodymium Drivers
- RF Frequency Range: 2.4GHz-2.48GHz
- Operating Distance: 10–20m (free space)
- Bluetooth Music Playtime: Up To 25hrs
- Wired Music Playtime: Up To 29hrs
- Talk Time: Up To 28hrsStandby Time: Up To 1300hrs(around 50days)
- Battery: 650mAh Li–Polymer Rechargeable Battery
- Support Profile: aptX®, A2DP, AVRCP, HSP, HFP
- Operating Environment: −10 to 50°C

Technical specifications are subject to change without notice, we apologize for any inconvenience

# FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.