




Ref -10 dBm      Att 20 dB      RBW 100 kHz    Marker 1 [T1 ]  
 VBW 300 kHz      -16.61 dBm  
 SWT 25 ms      22.600000 ms



Duty Cycle:

$$= \frac{(22 \times 0.29) + (9 \times 0.58)}{100} \text{ ms}$$

$$= \frac{11.6}{100}$$


$$= 0.116$$

Average Factor

$$= 20 \log(0.116)$$

$$= -18.7 \text{ dB}$$


Date: 4.SEP.2009 13:45:27




Date: 4.SEP.2009 13:47:51




Ref -10 dBm Att 20 dB RBW 100 kHz Delta 1 [T1 ]  
VBW 300 kHz -5.50 dB  
SWT 5 ms 580.000000 μs



Date: 4.SEP.2009 13:48:48



Date: 4.SEP.2009 13:35:25



Date: 4.SEP.2009 13:37:45




RBW 100 kHz Marker 1 [T1 ]  
VBW 300 kHz -16.39 dBm  
SWT 1 s 348.600000 ms

Ref -10 dBm

Att 20 dB

I PK  
MAXH



Center 433.99144 MHz

100 ms/

Date: 4.SEP.2009 13:42:32




RBW 100 kHz Marker 1 [T1 ]  
VBW 300 kHz -16.59 dBm  
SWT 100 ms 22.600000 ms

Ref -10 dBm

Att 20 dB

L PK  
MAXH



Center 433.99144 MHz

10 ms/

Date: 4.SEP.2009 13:40:20