




PSD NVNT n20 5240MHz Ant2




PSD NVNT n20 5260MHz Ant1




PSD NVNT n20 5260MHz Ant2




PSD NVNT n20 5280MHz Ant1




PSD NVNT n20 5280MHz Ant2




PSD NVNT n20 5320MHz Ant1




PSD NVNT n20 5320MHz Ant2




PSD NVNT n20 5500MHz Ant1




PSD NVNT n20 5500MHz Ant2




PSD NVNT n20 5600MHz Ant1




PSD NVNT n20 5600MHz Ant2




PSD NVNT n20 5700MHz Ant1




PSD NVNT n20 5700MHz Ant2




PSD NVNT n20 5745MHz Ant1




PSD NVNT n20 5745MHz Ant2




PSD NVNT n20 5785MHz Ant1




PSD NVNT n20 5785MHz Ant2




PSD NVNT n20 5825MHz Ant1




PSD NVNT n20 5825MHz Ant2




PSD NVNT n40 5190MHz Ant1




PSD NVNT n40 5190MHz Ant2




PSD NVNT n40 5230MHz Ant1




PSD NVNT n40 5230MHz Ant2




PSD NVNT n40 5270MHz Ant1




PSD NVNT n40 5270MHz Ant2




PSD NVNT n40 5310MHz Ant1




PSD NVNT n40 5310MHz Ant2




PSD NVNT n40 5510MHz Ant1




PSD NVNT n40 5510MHz Ant2




PSD NVNT n40 5570MHz Ant1




PSD NVNT n40 5570MHz Ant2




PSD NVNT n40 5670MHz Ant1




PSD NVNT n40 5670MHz Ant2




PSD NVNT n40 5755MHz Ant1




PSD NVNT n40 5755MHz Ant2



PSD NVNT n40 5795MHz Ant1



PSD NVNT n40 5795MHz Ant2



23.1.5 Band Edge

Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	a	5180	Ant1	-47.65	-27	Pass
NVNT	a	5240	Ant1	-47.01	-27	Pass
NVNT	a	5260	Ant1	-47.6	-27	Pass
NVNT	a	5320	Ant1	-47.27	-27	Pass
NVNT	a	5500	Ant1	-45.57	-27	Pass
NVNT	a	5700	Ant1	-46.24	-27	Pass
NVNT	a	5745	Ant1	-36.77	*	Pass
NVNT	a	5825	Ant1	-30.07	*	Pass
NVNT	a	5180	Ant2	-45.63	-27	Pass
NVNT	a	5240	Ant2	-47.54	-27	Pass
NVNT	a	5260	Ant2	-47.36	-27	Pass
NVNT	a	5320	Ant2	-47.32	-27	Pass
NVNT	a	5500	Ant2	-39.31	-27	Pass
NVNT	a	5700	Ant2	-45.73	-27	Pass
NVNT	a	5745	Ant2	-34.9	*	Pass
NVNT	a	5825	Ant2	-38.78	*	Pass
NVNT	ac20	5180	Ant1	-31.81	-27	Pass
NVNT	ac20	5180	Ant2	-37.25	-27	Pass
NVNT	ac20	5240	Ant1	-46.46	-27	Pass
NVNT	ac20	5240	Ant2	-48.49	-27	Pass
NVNT	ac20	5260	Ant1	-42.8	-27	Pass
NVNT	ac20	5260	Ant2	-46.94	-27	Pass
NVNT	ac20	5320	Ant1	-40.88	-27	Pass
NVNT	ac20	5320	Ant2	-36.42	-27	Pass
NVNT	ac20	5500	Ant1	-38.26	-27	Pass
NVNT	ac20	5500	Ant2	-38.6	-27	Pass
NVNT	ac20	5700	Ant1	-37.58	-27	Pass
NVNT	ac20	5700	Ant2	-34.37	-27	Pass
NVNT	ac20	5745	Ant1	-34.26	*	Pass
NVNT	ac20	5745	Ant2	-25.4	*	Pass
NVNT	ac20	5825	Ant1	-39.42	*	Pass
NVNT	ac20	5825	Ant2	-34.97	*	Pass
NVNT	ac40	5190	Ant1	-47.33	-27	Pass
NVNT	ac40	5190	Ant2	-48.48	-27	Pass
NVNT	ac40	5230	Ant1	-48.43	-27	Pass
NVNT	ac40	5230	Ant2	-48.28	-27	Pass
NVNT	ac40	5270	Ant1	-49.24	-27	Pass
NVNT	ac40	5270	Ant2	-48.5	-27	Pass
NVNT	ac40	5310	Ant1	-47.74	-27	Pass
NVNT	ac40	5310	Ant2	-47.12	-27	Pass
NVNT	ac40	5510	Ant1	-46.56	-27	Pass
NVNT	ac40	5510	Ant2	-47.57	-27	Pass