


DD1522 valid channels selection



Additional function

> Press P1+button or P1-button (P1+button+ P1+button+P1selecting the channel (channl P1-button)×1 button,hold on 1 to channel 15) you need Stop×1 The screen The screen The screen 5 will display C 5: will display 15 will display o OK Settina is ok

Note: The channel, which we used here, refers to the product control channel, rather than the channel of transmission frequency, only one transmission frequency is 433MHz.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

DD1520/DD1522 Emitter Specification



Fucntion instruction

DD1522 fifteen channels double control emitter: each channel had the same function with DD1520. One number of LCD screen means one control channel. Press "channel choose" button D+ (number descending) or P++ (number increasing) to change the channel. On the analogy of this, loose

finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show "o" that means the group

control status. Under the status of group control, pressing a way button will

start the group-control function of a way of all the channels will be availabe.Pressing b way buttons will start the group-control function of b

Notice: transmitter do not exposed to moisture and strike, so as not to affect life.When you use transmitter, if found emission distance obviously short or less sensitive. please chance another same new batterv. Please

way, b way of all the channels will be availabe

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

have batteries for recycling.

Technical specification

• Input voltage: 3V

• Transmitting frequency: 433MHz

• Transmitting power: 10 milliwatt

• Operating temperature: -10°C-50°C

• Transmssion distance: 200 meters open office,

35 meters on two walls