FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-English:

This device complies with Industry Canada RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-French:

Leprésent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio Exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, meme si le brouillage est susceptible d'en compromettre le fonctionnement."

Control System CE

DD1520 DD1522
Emitter Specification

T Type specification
Technical support

DD1520 Single-channel emitter
- Up button
- Stop button
- Down button
- Setting button (P2)
- Channel descending button (P1-)

DD1522 15-channel LCD emitter
- Up button
- Stop button
- Down button
- Channel increasing button (P1+)
- Setting button (P2)
- Channel descending button (P1-)

DD1520 DD1522 Back
- Battery

T Technical support
Technical support

Technical specification	Function instruction
• Input voltage: 3V (AAA battery×2) • Transmitting frequency: 433.925MHz • Transmitting power: 10 Milliwatt • Operating temperature: -5°C ~ 50°C • Transmission distance: 35 meters	DD1520 is single-channel emitter. DD1522 is 15-channel LCD emitter, one number of LCD screen means one control channel. Press channel descending button (P1-) or channel increasing button(P1+) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show "o" that means all channels if effective (group control state). Under the bidirectional mode, hold down a button for more than 5 seconds, and the wireless stop launch; Long press the up button or down button for more than 5 seconds, and then release, will sending loose button commands. When the voltage is less than 2.6V, there will be a low voltage indication.

⚠ Notice: Emitter couldn't be exposed to moisture and striked, so as not to affect life. When you use emitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling.
Caution: Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.

## A The valid channels selection of DD1522
Additional function

(P1+button+ P1-button)×1 Press P1+button and P1- button at the same time, hold on

The screen will show C

⚠ ①In the setting state, press the up or down button you can quit quickly;
②If you want to change the valid channels, reset it.

Press P1+button or P1-button, selecting the channel (channl 1 to channel 15) you need

The screen will show 15

Stop button×1

The screen will show o **OK**

Setting is ok

A Unidirection / bidirectional mode switching of DD1522
Additional function

Emitter without battery → Hold down P2 to load battery

Shows " 1 " → Unidirection mode

Shows " 2 " → Bidirectional mode

⚠ Factory default is bidirectional mode, repeated operation can be cyclical switching.

A Combination button lock/ unlock status of DD1520
Additional function

Long press stop button 15s above

LED flashes×1 → Switch to the combination button lock status

LED flashes×2 → Switch to the combination button unlock status

⚠ ① Factory default is the combination button unlock status, repeated operation can be cycle switching. ② The combination button is locked, the combination button is invalid, and the combination button is pressed without sending code. ③The combination button is locked and only affects the emitter code.

A Combination button lock/ unlock status of DD1522
Additional function

Long press stop button 15s above

Shows " L " → Switch to the combination button lock status

Shows " U " → Switch to the combination button unlock status

⚠ ①Factory default is the combination button unlock status, repeated operation can be cycle switching. ②The combination button is locked, the combination button is invalid, and the combination button is pressed without sending code, and there is no icon display; in the unlock state, the combination button is pressed with an icon flashing indication;
②The combination button is locked and only affects the emitter code.