

BT-1 manual



Specification:

Input Voltage: 9.6-14.4V

Current rating: < 5A





Speaker impedance: 4 ohm or above

Connecting to Bluetooth


Check for BT144 broadcast name and select with a passcode 0000.

After connection successful, a beep tone will be heard.

Functions

- Power ON/OFF: Long press  to turn ON. Short press to turn OFF
- Volume Control: Press + or – to increase volume or decrease volume. Long press + or – will reduce volume continuously.
- Fast forward / Fast Rewind: Press once to skip to next or last song. Long press to rewind or forward continuously.
- External Trigger: Press once  or  to activate the external EXT1 or EXT2. After triggered, the EXT1 or EXT2 will provide 12V voltage. The EXT1 and EXT2 will toggle the output between 12V and 0V.
- Play/Pause: Use  to play or pause the music.


Wire Connection



Connection will be as above figure. Do not connect speaker with impedance lower than 4 ohm.

Electronic Crossover

There is a red wire in a loop. When the red wire loop is cut, the rear speaker will be used to drive a subwoofer (4 ohm or above subwoofer speaker).



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.