


DUO



Name: Bluetooth Speaker
Model: SP58087 DS-1377



- | | |
|--|--------------------------|
| 1. Mode indicator | 6. Previous track |
| 2. Volume up | 7. AUX audio input |
| 3. Volume down | 8. Charging indicator |
| 4. Next track | 9. Stereo pairing button |
| 5. Press: Play/Pause;
Hold: Bluetooth pairing | 10. USB charging port |
| | 11. Power On/Off switch |

INDICATORS

INDICATOR		STATUS
◆ Stereo	Blink in blue/green	Connecting
	Light in green	Connected
✶ Bluetooth	Blink in red/blue	Pairing
	Light in blue	Paired
#1 in diagram	Light in red	Line-In Mode
🔋 Battery	Light in red	Charging
	#8 in diagram	Light in green

*Prompt sound will alert when the battery is low.

SPECIFICATIONS

- Model No.: SP58087 DUO
- Output power: 3W (THD=10%)
- Bluetooth A2DP, AVRCP function
- Battery (Li-ion) capacity: 900mAh
- Frequency Response: 80Hz–18KHz
- S/N Ratio: Line in/Bluetooth >65dB
- Efficient working distance: within 32ft (10m)

STEREO PAIRING

1. Turn on the speakers.
2. Press and hold the **STEREO buttons** (#9) on the back of each speaker simultaneously to connect.
3. **Mode indicators** (#1) will blink in green and blue (stereo pairing mode). They will be green steady lights when the speakers are connected.
*The first time that you connect your speakers for stereo use, it will take about a minute, to search and confirm the connection.
4. After the stereo connection, select one speaker and hold the **Play/Pause button** (#5) to pair the speaker with audio sources. The indicator will blink in red and blue (bluetooth pairing mode).
5. Follow the instructions of your device to pair the unit.
6. Select "DUO" from the Bluetooth list on your device. The indicator will be green and blue when it's connected successfully.

Note:

- The main speaker, which pairs with your smartphone or other Bluetooth devices, will be on the "L" channel; the other will be the auxiliary speaker on the "R" channel.
- While using the speakers in stereo, if you turn off the main speaker, the music will stop; if you turn off the auxiliary speaker, the main speaker will continue to play L and R channels mixed.
- This model can be used as two speakers (surround stereo sound) together, or also be used independently (R/L channels mixed).
- After two speakers are connected, if music stops please repeat the steps above.

SINGLE SPEAKER MODE

1. They are automatically set-up to connect in stereo mode after the first stereo pairing.
2. To use them individually, press one of the **STEREO buttons** for 3-5 seconds. They will disconnect from each other and will not automatically pair the next time you use them.
3. To pair the speaker with your device, hold the **Play/Pause button** and follow steps 4 to 6 above.
4. You can also disconnect them while you are using them in stereo mode. Press-and-hold the **STEREO button** either on the auxiliary speaker OR on the main speaker.

Note:

- To connect two speakers again, press and hold the **STEREO buttons** on both speakers simultaneously.
- If you disconnect from the main speaker, you will disconnect from the both speakers.
- The efficient distance is within 32ft (10m). Beyond 10m, the signal will be weak and disconnected.
- When the speakers are not in use, turn the speakers off.

AUDIO CONTROLS

1. Follow the instructions for pairing your Bluetooth Device.
2. Adjust the volume by pressing the - (#3) or + (#2) buttons .
3. Skip to the previous song or next song by using the buttons (#4 or #6).
4. Press pause button on the speaker to play/pause the song.

AUX-IN MODE

1. Connect the speakers and audio source (like iPhone, laptop, etc) with the AUX cable.
2. The volume can be adjusted separately on each speaker, not synchronized.

CHARGING THE UNIT

Connect your DUO speaker to any computer or an AC adaptor with a USB port by using the included USB-to-Micro USB cable.

SAFETY INFORMATION

WARNING:

Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Battery/Charger Hazard

1. It's dangerous if you replace the battery improperly.
2. You can only use the same type or equivalent type of battery to replace the damage one .
3. Battery shall not be exposed to overheating environment such as sunshine and fire .

Warning:

To reduce the risk of electric shock, do not remove cover (or back). Refer servicing to qualified service personnel.

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

- Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out.
- Unplug the charger from the electrical plug and the product when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the battery.
- Always try to keep the battery between 0°C and 45°C (32°F and 113°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Fire and Electric Shock Hazard

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the speaker. Such actions could result in electric shock.
- Clean the speaker only with a dry cloth.
- Do not expose your speaker to extremely high or low temperatures.
- Do not leave your speaker in direct sunlight for extended periods of time.
- Do not leave your speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

CAUTION:

- Do not use abrasive cleaners to clean your speaker. It could cause scratches and damage.
- Do not bring your speaker in to contact with any sharp objects. It could cause scratches and damage.
- Do not insert anything into your speaker unless otherwise specified in the user instructions. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your speaker yourself, it does not contain any user-serviceable components.
- Do not attempt to replace your speaker battery, it is built-in and is not changeable.
- Use only the manufacturer supplied charger to charge your speaker. Other chargers may look similar, but using them could result in electric shock and could damage.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your speaker prior to boarding an aircraft. Do not use the speaker inside an aircraft unless allowed by your airline.
- Dispose of the speaker and its battery in accordance with local regulations. Do not dispose of the battery with regular household waste.

Automobile Accident Hazard

- Do not leave or store the DUO speaker or any of its accessories near or over your automobile's air bag as serious injury may result when an air bag deploys.

Fall Hazard

- Do not place the DUO speaker on high surfaces such as shelves. During music playback the DUO speaker may move which could cause the speaker to shift and fall off of the edge.

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or on experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RS5 standard(s). Operation is subject to the following two conditions;
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.



Made in China exclusively for
iWave Sicura Media, Inc.
New York NY 10018
support@iwaveaudio.com
www.iwaveaudio.com



iWave and the iWave logo are registered trademarks of iWave Sicura Media, Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by iWave is under license. All other trademarks and trade names are those of their respective owners.



This product is not a toy.

www.iwaveaudio.com