Features:


Wireless Outdoor Sensor:

- Wall Mount or Table Stand
- One Wireless temperature Sensor Included
- 433.92MHz RF transmitting frequency
- 60 meter transmission range in an open area

▶ Battery: 2 x LR03 AAA

Main Unit Appearance

Wireless Outdoor Sensor



A1: Breathable gate A2: Hanging hole

A3: battery compartment

Operation:

- ▶ Replace Wireless Outdoor Sensor battery compartment cover ,Open main unit battery compartment cover ,Insert 2 x AAA batteries observing polarity ["+" and "-" marks]
- ▶ Wireless Outdoor Sensor after electrify, 31 seconds automatically transmit one signal. At the same time, the LED lights inside the product 1 times

Installation:

The remote sensor should be securely mounted onto a horizontal surface.

Note: Transmissions between receiver and transmitter can reach up to 60m in open area. Open Area: there are no interfering obstacles such as buildings, trees, vehicles, high voltage lines, etc.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

 The device has been evaluated to meet general RF exposure requirement.

 The device can be u sed in portable exposure condition without restriction