

**BATTERY CAUTION:**

1. Alkaline battery is recommended.
2. Non-rechargeable batteries are not to be recharged.
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Rechargeable batteries are only to be charged under adult supervision.
5. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
6. Do not mix old and new batteries.
7. Only batteries of the same or equivalent types as recommended are to be used.
8. Batteries are to be inserted with the correct polarity.
9. The supply terminals are not to be short-circuited.
10. If batteries are loose, bend out the contacts for a tighter fit.
11. Exhausted batteries are to be removed from the toy and be disposed of immediately; never dispose of batteries in fire.
12. If storing product for long periods of time, make sure to remove batteries.
13. Check the product periodically for signs of damage to electrical parts; do not play with product until damage has been properly assessed.

If the unit malfunctions, please remove the batteries for one minute and reinstall again.
If the malfunctions persist, please replace with new batteries.
BATTERIES SHOULD BE INSTALLED BY ADULTS ONLY.

**WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years****AGES
3
AND UP****Battery Requirement For
the Controller:**1 x 9V/6F22 battery
(not included).**Battery Requirement For
the Car:**3 x 1.5V "AA" batteries
(not included).Don't Put In Trash.
Recycle or Dispose as
Hazardous Waste.


Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ContentController.....x 1pc
Car.....x 1pc**Battery Installation- Car**

1. Make sure the power switch is on OFF position (Pic.1).
2. Use a screwdriver to loosen the screw on the battery case anti-clockwise (Pic.2).
3. Open the battery door (Pic.3).
4. Put 3 x AA batteries in the battery compartment as per the polarities shown inside (Pic.4).
5. Close the battery door and tighten the screw clockwise.

Battery Installation- Controller

1. Use a screwdriver to loosen the screw on the battery case anti-clockwise (Pic.5).
2. Put 1 x 9V battery in the battery compartment as per the polarities shown inside (Pic.5).
3. Close the battery door and tighten the screw clockwise.

**FCC Statements**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply within the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harm to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Colors & contents may vary.

Please keep this packaging for future reference.

Conforms to the safety requirements of ASTM F963.



©2010 PLAYMIND LTD.
Room 413-415, Houston Centre,
63 Mody Road, Tsim Sha Tsui East,
Kowloon, Hong Kong
Email:info@playmindltd.com
Visit us at: www.playmindltd.com
2010 Rev 1.0

How To Control**FEATURES :**
Forward, Reverse Turn**DESIGN.D**EDMOND 2009 Nov 03
2009 Nov 05
2009 Nov 06**SALE.D****ENGINES.D****PRODUCTION.D****DIRECTOR.D**