

1. Product Description

Avantree Audition is the latest Bluetooth 4.0 stereo headphones with microphone from Avantree family. It features with over the ear design which will be much more comfortable. With NFC function, you can touch your phone to it and the headphones will turn on, connect or disconnect. They are light weight and stylish. The buttons on the ear cup allow you to play and pause your music streaming, receive calls, adjust the volume etc. It can connect two devices and the battery can last a whole week (up to 40hrs)! Even if the battery is low, you can plug them in with the audio cable and use like wired headphones!

2. Product Overview





3. Charging

Avantree Audition uses universal micro charging socket.

USB charger requirements: 5V/500mA-2A

- 1) Each charge cycle will take about 3 hours.
- 2) The LED will indicate red when charging and will turn off when charging is complete.

Note: When battery power is low, the LED indicator will flash red and you will hear a beep sound every one minute.

4. Pairing

It is important to pair the headset with your Bluetooth enabled device (such as mobile phone, tablet etc.) for first time use. We find most of the online technical support questions are caused by improper pairing between the headset and the Bluetooth device. Please follow the above instructions step-by-step.

We take Bluetooth enabled mobile phone as example.

NFC pairing -

- A. Turn on NFC function from your phone.
- B. Let your phone tap NFC location of the headphones until your mobile phone give an indicate note. (Some phones will vibrate and some will have a beep sound.)
- C. Then your phone will get a reception request if you would like to pair with the headphones for the first pairing time.
- D. Tap "Yes", then your mobile phone will connect with Audition.
- E. Tap it again to turn the headphones off.

Normal Bluetooth pairing -

If your phone doesn't support NFC, you can follow the following steps to pair.

- A. Ensure the headset is off.
- B. Press and hold the MFB (multiple function button) about 7-10 seconds until the LED blinks **blue** and **red** alternately.
- C. Search for the headset from your phone.

- D. Once "Avantree Audition" is found in the search list, follow the indicated steps to pair (some phones may request the pin code "0000").
- E. Connect the headset to your phone.
- F. Your headset is now ready for use.

Turn on: From off, press and hold "MFB" for around 4 seconds, until the LED indicator shows blue.

Note: Once paired and connected, the head set will be automatically connected to your phone whenever you turn the headset on again, provided your phone is within range.

Turn off: From on, press and hold "MFB" for around 4 seconds until the LED indicator shows red.

Wired connection -

When the battery is low, you can use the 3.5mm audio cable to stream the music, just like the wired headphones.

Note: the buttons on the headphones will not work at this connection.



Pairing with two mobile phones -

A.From off, press and hold button MFB for 7-10 seconds until the LED indicator blinks blue and red alternately, then pair with the first phone as per normal.

B.Then turn it off, press and hold MFB button again until the LED indicator blinks blue and red again, then pair with the second phone in the normal manner.

C.Power off the headset, and then turn it on again. It will automatically connect with the last paired phone, and please connect with the first phone manually. Then the two phones will be connected with the headset.

5. Basic Operations:

- Answer a call: Press "MFB" once to answer the call.
- End a call: Press the "MFB" button once to end a call.
- Reject a call: Double click "MFB" button to reject a call.
- Voice Dial / Command: Short press both "V+" and "V-" whilst in standby mode, say the voice tag after you hear the alert. (Note: Make sure your phone supports voice dialing / command.)

- Last number redialing: In standby mode, double click "MFB" button.
- To switch a call between headset and mobile phone: During a call, press and hold "MFB" for 3 seconds to transfer the call.
- To Mute & Unmute during a conversation: Press and hold the "V+" button until you hear a short beep. In mute status, you will hear two short beeps every 3 seconds. To unmute the microphone, press and hold the "Next" button again until you hear a further short beep.
- To Restore Default Settings: In standby mode (just turn it on), press and hold "V+" and "V-" button for 8 seconds until the indicator flashes blue and red. The headphone has now been reset to its original settings. After being powered on again, it will enter pairing mode automatically.

5.1 Music Streaming

Please activate your phone's music player before listening to music on the headset. For some phones, music will automatically be heard on your headset, other phones you will need to manually transfer music from your phone to the headset.

- Volume Up: Press and hold the "V+" button.
- Volume Down: Press and hold the "V -" button

- To Play Music: Press the "MFB" button.
- PausePress the "MFB" button again.
- Previous Track Short press the "V-" button.
- Next Track Short press the "V+" button.

Notes: Some functions are dependent on the mobile phone being used with the headset. Therefore, certain features might not work with all phones as some phones do not support them.

5.2 Advanced Operations - Multipoint

5.4.2 Answer a second call during a call (3 way call or two link function) When a second call is received -

Press and hold "V+" button for 2 seconds to hold the first call and answer the second call.

Press "MFB" once to answer a second call and end the first call simultaneously.

5.4.3 Switch between 2 phone calls (3 way call or two link function)

When two calls are in progress, press and hold the "V+" button for 2 seconds to switch between each call.

To end the currently active call and switch to the other call, short press the "MFB" button once.

6. Working with a PC or Laptop

For computers running Microsoft Windows with Built-in Bluetooth
supporting A2DP. For other systems, you might need a Bluetooth dongle to
work with your computer. Your Bluetooth headset doesn't need any special
drivers to set up. For any updated driver information, please refer to your
computer manufacturer or to the dongle manufacturer.

6.1 Pairing procedure:

- A. Ensure your computer has built-in Bluetooth as above and that Bluetooth is turned on.
- B. Double click the Bluetooth icon and click "Add a new device".
- C. Once the "Avantree Jogger Pro" is found in the search list, follow the steps indicated by the computer. If asked for a pin code during this process, enter "0000".
- D. Pair the headset to your PC.

E. Your headset is now ready for use.

6.2 Streaming Music

Before streaming music, you need to change the sound settings. Go to "Control Panel" – "Sound" – "Playback" and change the audio setting to "Bluetooth Stereo Audio".

6.3 For Skype Calls

- Some systems can change the required sound settings automatically and you can make Skype calls immediately.
- Other systems will need changes to the sound settings before you are able
 to make Skype calls. Go to "Skype Tools" "Options" "Sound Devices".
 Select each of the "Audio in" / "Audio Out" / "Ringing" options and change all
 three modes to "Bluetooth AV Audio" then save the settings. You will then be
 able to make Skype calls.

7. Product Specification

• Bluetooth V4.0 with EDR

• Support profiles: Headset, Handsfree, A2DP, AVRCP

• Operational range: Class 2, 10 meters

• Battery: 450mA rechargeable lithium battery

Talk time: up to 50 hrs
Music time: up to 40 hrs
Standby time: up to 20 days
Headset weight: 180g

• Headset size: 170mm(L)x180mm(W)X80mm(H)

The talk and standby times may vary when used with different mobile phones or other compatible Bluetooth devices and are also dependant on different usage styles, settings and operating environment.

8. Safety Information

- To avoid any damage to or malfunction of the device, do not drop it from high places.
- Keep this device away from water, other liquids or high humidity environments.
 If the device is exposed to water, other liquids or excessive moisture, do not operate it. This will avoid risk of electrical shock to yourself and risk of explosion or further damage to the device.
- Do not place or keep this device near any heat source, such as direct sun light, radiators, stoves or other apparatus which produces heat. It may cause the battery to explode, or degradation of battery performance and life.
- Do not attempt to modify, repair or disassemble this device yourself.
 (Especially the battery: Interfering with the battery may cause an explosion).
 Attempting to modify or repair the device yourself this will void the warranty.
- · Do not place heavy objects on this device.
- Use only the supplied or other approved chargers.
- Replacement or repair must be performed by a qualified service center or by the manufacturer.
- Unplug this device when unused for long periods of time or during lightning storms.

CAUTIONS: ELECTRIC SHOCK HAZARD

The battery in this device may present a risk of fire or chemical burns if mistreated.

9. Declaration of Conformity

9.1. EU

This product is CE certified according to the provision of the R&TTE Directive (99/5/EC).

We declare that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

9.2. Trademark Statement

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc.

Avantree is a trademark owned by Avantronics limited.

10. Warranty

Please refer the warranty card included in the pack.

11.Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.