

# Amplify Tablet

## User Manual

© 2014, Amplify Education, Inc.

All rights reserved.



# Contents

Introduction.....	1
Get to know your Amplify Tablet .....	1
Basic care tips.....	1
Getting help.....	1
Important safety information.....	2
Attention: Teachers, parents and adult supervisors.....	2
Safety precautions .....	23
Tablet overview.....	4
Front view.....	4
Rear view .....	5
Left side view.....	6
Indicators .....	7
Basic tablet functions.....	8
Charging the battery.....	8
Powering on and off.....	8
Putting your tablet to sleep.....	8
Using MicroSD cards.....	9
Getting help.....	10
Federal Communications Commission interference statement.....	11
RF exposure warning.....	12



# Introduction

## Get to know your Amplify Tablet

It's been designed with you in mind. In collaboration with educators across the county, we built the Amplify Tablet specially for teaching and learning.

### Basic care tips

Please read this manual for important safety information and instructions for use. Follow the basic care tips below and your Amplify Tablet should stay in top shape. Enjoy!

- It's fragile — Don't drop or scratch your tablet. Keep it in the protective case provided.
- No liquids! No food! — Keep water and other liquids as well as dust and dirt away from your tablet.
- Screen cleaning — Only use recommended cloths and sprays, like eyeglass cleaner (available at most drugstores). Avoid glass cleaners like Windex®, which will harm it.
- Temperature — Room temperature please. Don't leave it in a cold or hot car, in direct sunlight or near a heating vent.
- Keep tabs — Don't leave your tablet unattended.
- Rest position — Don't place it on an uneven surface or stack things on top of it.
- Protection — Don't let your pet (or baby brother!) play with it.
- Charging — Only use the charger that came with your tablet, and keep the power cable out of the way of people or pets who might trip.

### Getting help

Amplify's support team is here to help. If you need assistance with your tablet, call 1-888-975-1431, email [tabletsupport@amplify.com](mailto:tabletsupport@amplify.com), or visit [amplify.com/support](http://amplify.com/support).

# Important safety information

## Attention: Teachers, parents and adult supervisors

This product is an educational tool designed for school children. There must be supervision by an adult when school children under 10 are using this tablet. Please provide a thorough explanation to all students on safe and proper handling of the tablet and power cord.

### **Be sure to keep the power cord away from young children.**

Please ensure that students understand and follow these precautions to reduce the risk of serious injury or death from electric shock, fire, or other hazards:

- This device is an educational tool and not a toy. The tablet and power cord should be handled properly and not be dropped, crushed, stepped on or otherwise abused.
- Keep out of reach of children under 3 years of age.
- The teacher, parent or adult supervisor should periodically inspect the tablet, charger and power cord for damage. If there is any damage, remove the tablet from use and contact the Service Center.
- Students should report any damage (including cracked screen) or loose parts to their teacher, parents or adult supervisor immediately.
- Do not leave the tablet plugged in or “on” when enclosed in a non-vented container, such as a school backpack, as overheating may occur. Instead, turn off the device or place it in “sleep” mode.
- Long-term exposure to loud sounds at high volume may result in permanent hearing loss. When using headphones or earbuds, listen at lower volumes for short periods of time. Set the volume while in a quiet environment. Turn the volume down if you cannot hear people speaking near you. The louder the volume, the less time is required before your hearing may be affected. If you experience ringing in your ears or hear muffled speech, stop listening and have your hearing checked.
- The tablet must be used with the supplied charger only.

### Safety Don'ts:


- Don't place near fire or other sources of heat.
- Don't expose to magnetic fields.
- Don't expose to rain or moisture.
- Don't place heavy objects on the tablet.

- Don't drop the tablet.
- Don't eat or drink near the tablet.
- Don't spill liquid of any kind on the tablet as it may render it inoperative.
- Don't submerge the tablet in water.
- Don't expose the tablet to extreme temperatures or direct sunlight.
- Don't try to dismantle the tablet.

For additional information about using the tablet, go to <http://www.amplify.com/support>.

# Tablet overview

## Front view




	Name	Function
1	Light sensor	Detects the ambient light and adjusts the screen brightness automatically
2	Front-facing camera	1.26 MP front camera
3	Microphone	Internal microphone
4	Touchscreen	10.1-inch 1280x800 HD touchscreen with multi-touch feature
5	Stylus slot	For storing the stylus
6	Connectors and ports	See "Left side view" for details

## Rear view



	Name	Function
1	Power button	Press quickly to enter sleep mode or wake from sleep mode; press and hold to power down or up
2	Rear-facing camera	5.0 MP rear camera
3	Microphone	Internal microphone
4	Volume up/down	Press the top to increase the volume; press the bottom to decrease the volume
5	Speaker	Two built-in speakers (disabled when you connect headphones)

## Left side view



	Name	Function
1	Power connector	Plug in the AC adapter to charge your tablet
2	Headphone connector	Connect headphones or external speakers (shuts off the internal speaker)
3	MicroSD™ card slot	Insert a microSD card for additional storage
4	Micro HDMI® port	Use a micro HDMI-to-HDMI cable to connect to a TV or interactive whiteboard
5	Micro USB port	Use a micro USB-to-USB cable to connect the tablet to a computer to transfer files

# Indicators



	Name	Function
1	Front camera indicator	Lights up when the front camera is active
2	Battery charging indicator	Illuminated when the tablet is connected to the charger


# Basic tablet functions

## Charging the battery

It's important to charge your battery every night so it's ready for school the next day. It takes around 6-8 hours to charge fully. Use only the AC adapter that came with your tablet.

To charge the battery:


1. Insert the adapter cord into the power port on your tablet.
2. Plug the adapter into a standard grounded AC power outlet.
3. Make sure the power indicator at the left of the screen lights up, showing that the tablet is charging.



## Powering on and off

Press the power button at the left side of the tablet's top edge.

If the tablet is in sleep mode, it wakes up immediately and you're ready to begin. If it's powered off completely, hold the power button down until the Intel® logo appears.



## Putting your tablet to sleep

Press the power button to put your tablet to sleep. In sleep mode, the tablet uses minimal power and will restart almost instantly.


Your tablet will go into sleep mode automatically if you don't use it for a certain period of time (configured through the Display settings). If this happens, press the power button briefly to wake the tablet up and then enter your PIN.

## Using microSD cards

Your tablet supports microSD cards. You can insert or remove your microSD card without powering off the tablet.

### To install a microSD card:

- Insert your microSD card into the card slot as shown above.



### To remove a microSD card:

1. Push and release the microSD card to unlock it.
2. Pull the microSD card out of the slot.

# Getting help

Amplify's support team is here to help. Call 1-888-975-1431 or email [tabletsupport@amplify.com](mailto:tabletsupport@amplify.com). You can access help through the Support page on the tablet.

Before you call:

## Is it charged?



If the battery is empty, plug in the charger.

Let the tablet charge for a few minutes before trying to start it.

## Try restarting Wi-Fi



Swipe the clock down and then touch the SETTINGS icon. Slide the Wi-Fi switch to OFF, pause, and then slide the Wi-Fi switch back to ON.

## Connected to the internet?



If you have a weak signal or the indicator is gray, your tablet may not work properly.

## Try restarting the tablet.



Try restarting the tablet.

Hold down the power button and touch Power off. Then restart the tablet.

# Federal Communications Commission interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **CAUTION**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

### **RF Exposure Information (SAR)**

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The highest SAR value for the device as reported to the FCC is **1.377** W/kg when placed next to the body.