


Product Description

1. Blue/Orange Indicator
2. Power/Record button
3. Microphone
4. Lens
5. USB port
6. Reset button



Power On & Off

To turn on the DV, press and hold the Power/Record button until the Blue Indicator lights up. To turn off the DV, press and hold the Power/Record button until the Blue Indicator goes off. If the DV is idle for 1 minute or the battery is low, it will power off automatically.

Note: If Power-off by holding the Power/Record button fails, press the Reset button to power off the DV.

Taking Video

After switching on the DV, press (and not hold) the Power/Record button to start recording, press it again to stop. The Orange indicator will light up during video recording.

When memory full, Orange indicator won't light up.

To delete some video clip, first of all, the unit should be connected to computer, refer to the "Connected to Computer" for the details.

Note: The video clip will lose if the Reset button is pressed during video recording.

Connected to Computer

To playback or delete the video clips, the DV should be connected to the computer through the USB port. There will be a New Removable Disk Device. Click it and Open the "DCIM" folder. Your video clips are all in this folder. You can do deleting and playback right here. At the same time, the Blue indicator is flashing, it means the battery is charging too.

Charging Battery

To charge the battery, connect the DV to the USB port. It will start charging automatically, and the Blue indicator is flashing. When the battery is fully charged, the Blue indicator lights up and stop flashing.

Specification

Video Resolution	640 x 480 (VGA), 30 fps
Storage Included	2GB built in memory. Store up to 2 hours video clips
File Format	AVI
Weight (inc. battery)	18g
Dimensions	57mm x 21mm x 18mm

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.