





Ref 0 dBm Att 30 dB RBW 10 MHz Marker 1 [T1]
 VBW 10 MHz -5.30 dBm
 SWT 100 ms 32.224000 ms




Duty Cycle:
 $= \frac{0.021404 \times 14 \times 12}{32.224}$
 $= 0.1116$

Average Factor:
 $= 20 \log(0.1116)$
 $= -19.05$


Date: 25.AUG.2009 11:32:23



Date: 25.AUG.2009 11:38:29



Date: 25.AUG.2009 11:37:15



Date: 25.AUG.2009 11:45:47