





Ref 20 dBm Att 50 dB RBW 10 MHz  
 VBW 10 MHz SWT 100 ms



Duty Cycle:  
 $= \frac{0.242 \times 37}{100}$  ms  
 $= 0.08954$

Average Factor:  
 $= 20 \log(0.08954)$   
 $= -20.96$

Date: 25.AUG.2009 10:50:42



Date: 25.AUG.2009 10:54:24