



蓝牙+无线双模键盘
BT + Wireless dual-mode keyboard

Instruction Manual
使用说明书
ANNI

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the device and receiver.
--Connect the device into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to o perate the equipment

Instruction Manual

Thank you for selecting Geezer products, in order to let you further understand the use of this wireless keyboard and mouse set, please read this manual carefully before using it .

1.Package Contents


keyboard.....1PCS
nano receiver.....1PCS
manual.....1PCS

2.Product installing instructions


- Put 2 AAA(No. 7) batteries into the keyboard battery compartment (Note: pay attention to the positive and negative terminals of the battery compartment).
- Turn the power switch at the bottom of the keyboard to ON.
- Turn on the Bluetooth device of the computer, enter the Bluetooth search screen, and click the Bluetooth code on the keyboard Key FN+BT1, select Bluetooth (BT1) channel, long press the Bluetooth code key (more than 3 seconds), The green light of Bluetooth 1 channel blinks slowly, the keyboard enters the matching mode, and the computer searches for the device Name: ANNI BT. Click on the link to use.
- If the keyboard needs to be connected to another device at the same time, turn on the Bluetooth device of the computer and enter the Bluetooth Search interface, click the keyboard Bluetooth key FN+BT2, select Bluetooth (BT2) Channel, long press the Bluetooth code key (more than three seconds >, Bluetooth 2 channel green light slowly flash, keyboard forward Enter the matching code configuration, the computer searches the device name: ANNI BT click the connection to use.

5. If you need to switch to 2.4G mode, first plug the receiver at the bottom of the keyboard into the computer USB Interface, and then click the keyboard Bluetooth key FN+DEL, keyboard click FN+DEL key,Keyboard are selected to 2.4G connection, 2.4G mode keyboard automatic code, you can use.

3.product description wireless keyboard



A:Basic function description:

- 2-channel Bluetooth +2.4G 84-key crater keyboard.
- FN+BT1/BT2 Press to switch the Bluetooth channel.
- FN+  To switch to 2.4G channel mode.
- When switching to the current channel, the green light under this button will be on for 3~5 seconds.
- FN+BT1/BT2 can be switched to the channel in a single time, and long press for 3 seconds under the Bluetooth channel to pair the code.The light under the current button blinks slowly for up to 3 minutes to enter Bluetooth mode.
- Compatible systems can be switched through FN+Q/W/E.

The factory default is FN+W (Switch to Windows) This system is required on F1-F12 Use the FN key to trigger multimedia			
F1 x	Cut	FN+E (Switch to IOS)	FN+Q (Switch to Android)
F2 p	Copy	Copy	Copy
F3 a	Paste	Paste	Paste

F4 s	Lauguage Switch	Lauguage Switch	Lauguage Switch
F5 q	Search	Search	Search
F6 w	Previous Track	Previous Track	Previous Track
F7 d	Play/Pause	Play/Pause	Play/Pause
F8 e	Next Track	Next Track	Next Track
F9 r	Mute	Mute	Mute
F10 o	Volume Down	Volume Down	Volume Down
F11 l	Volume Up	Volume Up	Volume Up
F12 u	Screen Lock	Screen Lock	Screen Lock
Esc	Open the home page	Back to the main screen	Back to the main screen
Code matching mode: FN+BT1/BT2 Long press for code matching (the green light blinks slowly), short press to switch channels			


- There is a battery power switch at the bottom of the keyboard
- Applicable system in Bluetooth mode:
Windows – Windows8.0 or later is recommended
MacOS – MacOS10.10 or later is recommended
Android - Android4.3 or above is recommended
It can run in Windows XP,Vista, Windows 7, Windows 8/ in 2.4G mode Windows 10 and other operating systems
- Indicator Light Description:



ABT1



BT2

 :Low power indicator: When the battery voltage is lower than 2.2V, the red light blinks slowly.

 :2.4G channel indicator (green).

A :CAPS LOCK Switch indicator (red light) .

BT1 :Bluetooth channel 1 indicator (green).

BT2 :Bluetooth channel 2 indicator (green).

平保版

保修期限:	购买日期:	购买地点:	产品序列号:	章
产品维修记录				
维修情况				
日期				

备注: 请清楚填写各条目, 请勿擅自涂改, 并妥善保管好本保修卡, 以维护您的合法权益。如需服务或有任何疑问, 请与我们联系。



深圳摩天手科技有限公司
Shenzhen Mofii Electronics Co.,Ltd

深圳市宝安区沙井街道新沙路正诚丰科技园
ZhengChengFeng Technology Zone, Xinsha Road,
ShaJing Town, BaoAn Area, Shenzhen,China.

电话/Tel: 86-755-82507904 400-6788-010
邮箱/E-mail: mofii@mofii.com
网址/website: http://www.mofii.com

使用说明书

感谢您的支持, 为了使您更进一步的了解此无线键鼠套装的使用, 请您在使用前认真阅读此说明书!


1.包装内容物

键盘.....1PCS
接收器.....1PCS
说明书.....1PCS


2.产品安装说明

- 将2节AAA(7号)电池装入 键盘电池仓中(注:注意电池仓的正负极)。
- 将键盘底部的电源开关拨到ON。
- 打开电脑蓝牙设备, 进入蓝牙搜寻界面, 单击键盘蓝牙对码键FN+BT1, 选择蓝牙(BT1)通道, 长按蓝牙对码键(三秒以上), 蓝牙1通道绿灯慢闪, 键盘进入对码状态, 电脑搜寻到设备名:ANNI BT. 点击连接即可使用。
- 如果键盘需同时连接另一台设备, 打开电脑蓝牙设备, 进入蓝牙搜寻界面, 单击键盘蓝牙对码键FN+BT2, 选择蓝牙 (BT2) 通道, 长按蓝牙对码键(三秒以上), 蓝牙2通道绿灯慢闪, 键盘进入对码状态, 电脑搜寻到设备名:ANNI BT 点击连接即使用。
- 如果需要切换到2.4G模式, 首先把键盘底部的接收器插到电脑USB接口, 然后单击键盘蓝牙对码键FN+DEL, 键盘单击 FN+DEL按键, 键盘都选到2.4G连接, 2.4G模式下键盘自动对码, 即可使用。

3.产品描述 无线键盘



A:基本功能说明:

- 2通道蓝牙+2.4G 84键火山口键盘.
- FN+BT1/BT2单按是切换蓝牙通道.
- FN+  为切换到2.4G通道模式.
- 切到当前通道时这个按键下绿灯长亮3~5秒指示.
- FN+BT1/BT2 单按时为通道切换, 在蓝牙通道下长按3秒 为对码, 当前按键下面的灯慢闪最长3分钟, 进入蓝牙对码模式.
- 可以通过FN+Q/W/E切换兼容系统.

出厂默认FN+W (切换到Windows) 此系统下F1-F12上需要 配合FN键触发多媒体			
F1 x	剪切	FN+E (切换到IOS系统)	FN+Q (切换到Android系统)
F2 p	复制	复制	复制
F3 a	粘贴	粘贴	粘贴
F4 s	切换语言	切换语言	切换语言
F5 q	搜索	搜索	搜索
F6 w	上一曲	上一曲	上一曲
F7 d	播放/暂停	播放/暂停	播放/暂停

F8 e	下一曲	下一曲	下一曲
F9 r	静音	静音	静音
F10 o	音量-	音量-	音量-
F11 l	音量+	音量+	音量+
F12 u	锁屏(黑屏)	锁屏(黑屏)	锁屏(黑屏)
Esc	打开主页	回到主界面	回到主界面
对码方式: FN+BT1/BT2长按对码 (绿灯慢闪), 短按为通道切换			

- 键盘底部有一个电池电源开关
- 在蓝牙模式下适用系统:
Windows – 建议 Windows8.0 以上版本
MacOS – 建议 MacOS10.10以上版本
Android - 建议 Android4.3 以上版本
在2.4G模式下可以运行于 Win XP,Vista,Win7, Win8/
Win 10 等操作系统
- 指示灯说明:



ABT1



BT2

 :低电指示, 电池电压低于2.2V时红灯慢闪.

 :2.4G通道指示灯(绿灯) .

A :CAPS LOCK开关指示灯(红灯) .

BT1 :蓝牙通道1指示灯(绿灯) .

BT2 :蓝牙通道2指示灯(绿灯) .

产品中有害物质含量

部件名称	有害物质			
	铅 (Pb)	汞 (Hg)	铜 (Cu)	六价铬 (Cr (VI))
印刷电路板组件*	×	○	○	○
外壳及附件	×	○	○	○
本表格依据SJ/T 11364的规定编制。 ○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。 ×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 表中标记“×”的部件， 因全球技术发展水平限制而无法实现有害物质的替代。 印刷电路板组件*：包括印刷电路板及其零部件， 电子元器件等 根据产品型号不同， 您所购买的产品可能不会含有以上所有部件				
在中华人民共和国境内销售的电子电气产品必须标识此标志， 标志内的数字代表在正常的使用状态下 的产品的环保使用期限。				



合格证
QC
PASS